



# Barrel Shifter Module - Lattice Radiant Software

## User Guide

FPGA-IPUG-02088-1.0

February 2020

## Disclaimers

Lattice makes no warranty, representation, or guarantee regarding the accuracy of information contained in this document or the suitability of its products for any particular purpose. All information herein is provided AS IS and with all faults, and all risk associated with such information is entirely with Buyer. Buyer shall not rely on any data and performance specifications or parameters provided herein. Products sold by Lattice have been subject to limited testing and it is the Buyer's responsibility to independently determine the suitability of any products and to test and verify the same. No Lattice products should be used in conjunction with mission- or safety-critical or any other application in which the failure of Lattice's product could create a situation where personal injury, death, severe property or environmental damage may occur. The information provided in this document is proprietary to Lattice Semiconductor, and Lattice reserves the right to make any changes to the information in this document or to any products at any time without notice.

## Contents

Acronyms in This Document .....	5
1. Introduction .....	6
1.1. Quick Facts .....	6
1.2. Features .....	6
1.3. Conventions .....	6
1.3.1. Nomenclature.....	6
1.3.2. Signal Names .....	6
1.3.3. Attribute Names.....	6
2. Functional Description.....	7
2.1. Overview .....	7
2.2. Signal Descriptions .....	8
2.3. Attribute Summary.....	8
3. IP Generation, Synthesis, and Validation.....	10
3.1. Licensing the IP.....	10
3.2. Generating and Synthesizing the IP .....	10
3.3. Running the Functional Simulation .....	13
Appendix A. Resource Utilization .....	15
References .....	16
Technical Support Assistance .....	17
Revision History .....	18

## Figures

Figure 2.1. Barrel Shifter Block Diagram .....	7
Figure 3.1. Module/IP Block Wizard .....	10
Figure 3.2. Configure User Interface of Barrel Shifter Module .....	11
Figure 3.3. Check Generating Result .....	11
Figure 3.4. Simulation Wizard .....	13
Figure 3.5. Adding and Reordering Source .....	13
Figure 3.6. Simulation Waveform .....	14

## Tables

Table 1.1. Barrel Shifter Module Quick Facts .....	6
Table 2.1. Barrel Shifter Module Signal Description .....	8
Table 2.2. Attributes Table .....	8
Table 2.3. Attributes Descriptions .....	9
Table 3.1. Generated File List .....	12
Table A.1. Resource Utilization .....	15

## Acronyms in This Document

A list of acronyms used in this document.

Acronym	Definition
FPGA	Field Programmable Gate Array
RTL	Register Transfer Level
IP	Intellectual Property
MSB	Most Significant Bit
LSB	Least Significant Bit

# 1. Introduction

The Barrel Shifter Module is a pipeline shifter designed to shift a data word by the specified number of bits either in the left or the right direction. Zero Insert and Rotate types of shifts are available for shifts in either direction. In addition, the Sign Extension type is available for the shift in the right direction.

## 1.1. Quick Facts

Table 1.1 shows a summary of the Barrel Shifter Module.

**Table 1.1. Barrel Shifter Module Quick Facts**

<b>IP Requirements</b>	Supported FPGA Family	CrossLink-NX™
<b>Resource Utilization</b>	Targeted Devices	LIFCL-40, LIFCL-17
<b>Design Tool Support</b>	Lattice Implementation	Lattice Radiant® Software 2.0
	Synthesis	Lattice Synthesis Engine (LSE)
		Synopsys® Synplify Pro® for Lattice
Simulation	For the list of supported simulators, see the <a href="#">Lattice Radiant Software 2.0 User Guide</a> .	

## 1.2. Features

The key features of Barrel Shifter Module include:

- Configurable shift direction
- Configurable data width
- Configurable maximum number of shifts
- Configurable Reset Mode
- Supports Enable/Disable of Input, Output and Pipeline Registers
- Configurable Bus Ordering

## 1.3. Conventions

### 1.3.1. Nomenclature

The nomenclature used in this document is based on Verilog HDL.

### 1.3.2. Signal Names

Signal names that end with:

- *\_n* are active low
- *\_i* are input signals
- *\_o* are output signals

### 1.3.3. Attribute Names

Attribute names in this document are formatted in title case and italicized (*Attribute Name*).

## 2. Functional Description


### 2.1. Overview

The Barrel Shifter Module shifts a data word by a specified number of bits. Depending on the shift direction chosen, it shifts the values in the register to the left or to the right by the number of bits stipulated by `shift_i` signal. The right shift means shifting from MSB to LSB while left shift means shifting from LSB to MSB.

For left shift there are two possible shift types: Zero Insert and Rotate. When Zero Insert shift type is selected, the freed LSB bits are replaced by '0'. When Rotate shift type is selected, the freed LSB bits are replaced by MSB bits which came out of the word after left shift. For example, if the previous binary representation of eight bits original word is *1100 1001* and it is shifted to the left by 3 bits, then for Zero Insert shift type the result is *0100 1000* while for Rotate shift type the final result is *0100 1110*.

For right shift, besides described for left shift two shift types (Zero Insert and Rotate), there is one additional shift type called Sign Extension. For that shift type, the freed MSB bits are replaced by the original MSB bit's value. For example, if binary representation of the eight bits original word is *1101 1001* and it is shifted to the right by 3 bits, then for Sign Extension shift type the result is *1111 1011*. If the previous binary representation of eight bits original word is *0101 1001* (or original MSB was zero) and it is shifted to the right by 3 bits, then for Sign Extension shift type the final result is *0001 1011*.

There are two possible bus ordering modes: Big Endian and Little Endian. When Big Endian is chosen, the `data_i`, `shift_i` and `result_o` busses ordering is from MSB to LSB, otherwise from LSB to MSB.



where n = Data Width

**Figure 2.1. Barrel Shifter Block Diagram**

## 2.2. Signal Descriptions

**Table 2.1. Barrel Shifter Module Signal Description**

Port Name	I/O	Width	Description
<b>Clock and Reset Ports</b>			
clk_i	In	1	System clock input. Available if any of the following attributes is/are enabled: <i>Enable Input Register, Enable Pipeline Register or Enable Output Register.</i>
reset_i	In	1	Reset input. Available if any of the following attributes is/are enabled: <i>Enable Input Register, Enable Pipeline Register or Enable Output Register.</i>
<b>User Interface Ports</b>			
clk_en_i	In	1	Clock enable input. Available if any of the following attributes is/are enabled: <i>Enable Input Register, Enable Pipeline Register or Enable Output Register.</i>
data_i	In	<i>Data Width*</i>	Data input.
shift_i	In	5	Shift input. This signal shows the number of bits by which data input is shifted.
result_o	Out	<i>Data Width*</i>	Result output.

**\*Note:** The bit width of some signals is set by the attribute. Refer to [Table 2.2](#) for the description of these attributes.

## 2.3. Attribute Summary

The configurable attributes of the Barrel Shifter Module are shown in [Table 2.2](#) and are described in [Table 2.3](#). The attributes can be configured through the IP Catalog’s Module/IP wizard of the Lattice Radiant Software.

**Table 2.2. Attributes Table**

Attribute	Selectable Values	Default	Dependency on Other Attributes
<b>Configuration</b>			
Shift Direction	Left, Right	Left	—
Type	Zero Insert, Rotate, Sign Extension	Zero Insert	Sign Extension is only available when <i>Shift Direction == Right</i>
Data Width	2 – 40	36	—
Maximum Number of Shifts	1 – 35	31	—
Reset Mode	Sync, Async	Sync	Active if: <i>Enable Fully Pipelined Mode == Checked</i> or <i>Enable Input Register == Checked</i> or <i>Enable Output Register == Checked</i>
Enable Input Register	Checked, Unchecked	Checked	—
Enable Pipeline Register	Checked, Unchecked	Checked	—
Enable Output Register	Checked, Unchecked	Checked	—
Bus Ordering Style	Little Endian, Big Endian	Big Endian	—



**Table 2.3. Attributes Descriptions**

Attribute	Description
<b>Configuration</b>	
Shift Direction	Specifies the direction of the shift. Left: shifting from MSB to LSB, Right: shifting from LSB to MSB.
Type	For detailed description see <a href="#">Overview</a> section.
Data Width	Specifies the width of input and output data.
Maximum Number of Shifts	Specifies the maximum possible shift value coming from shift_i input.
Reset Mode	Specifies the mode of reset to be used. <i>Reset Mode</i> can only be configured if any of the following attributes is/are enabled: <i>Enable Fully Pipelined Mode</i> , <i>Enable Input Register</i> or <i>Enable Output Register</i> .
Enable Input Register	Specifies if input register is enabled or not.
Enable Pipeline Register	Specifies if the data pipeline is enabled or not.
Enable Output Register	Specifies if output register is enabled or not.
Bus Ordering Style	Specifies the bus ordering of shift, input and output data ports. Little Endian: the data_i, shift_i and result_o busses ordering is from LSB to MSB; Big Endian: the data_i, shift_i and result_o busses ordering is from MSB to LSB

### 3. IP Generation, Synthesis, and Validation

This section provides information on how to generate and synthesize this module using the Lattice Radiant Software. For more on Lattice Radiant Software, please refer to the [Lattice Radiant Software 2.0 User Guide](#) and relevant tutorials.

#### 3.1. Licensing the IP

No license is required for this module.

#### 3.2. Generating and Synthesizing the IP

The Lattice Radiant Software allows you to customize and generate modules and IPs and integrate them into the device's architecture. The procedure for generating the Barrel Shifter Module in Lattice Radiant Software is described below.

To generate the Barrel Shifter Module:

1. Create a new Lattice Radiant Software project or open an existing project.
2. In the IP Catalog tab, double-click on Barrel Shifter under Module, Arithmetic\_Modules category.
3. The **Module/IP Block Wizard** opens as shown in [Figure 3.1](#). Enter values in the **Component name** and the **Create in** fields and click **Next**.






Figure 3.1. Module/IP Block Wizard

- In the module's dialog box of the **Module/IP Block Wizard** window, customize the selected Barrel Shifter Module using drop-down menus and check boxes. As a sample configuration, see [Figure 3.2](#). For configuration options, see the [Attribute Summary](#) section.



**Figure 3.2. Configure User Interface of Barrel Shifter Module**

- Click **Generate**. The **Check Generating Result** dialog box opens, showing design block messages and results as shown in [Figure 3.3](#).



**Figure 3.3. Check Generating Result**

6. Click the **Finish** button. All the generated files are placed under the directory paths in the **Create in** and the **Component name** fields shown in [Figure 3.1](#).

The generated Barrel Shifter Module package includes the black box (<Instance Name>\_bb.v) and instance templates (<Instance Name>\_tmpl.v/vhd) that can be used to instantiate the module in a top-level design. An example RTL top-level reference source file (<Instance Name>.v) that can be used as an instantiation template for the module is also provided. You may also use this top-level reference as the starting template for the top-level for their complete design. The generated files are listed in [Table 3.1](#).


**Table 3.1. Generated File List**


Attribute	Description
<Instance Name>.ipx	This file contains the information on the files associated to the generated IP.
<Instance Name>.cfg	This file contains the attribute values used in IP configuration.
component.xml	Contains the ipxact:component information of the IP.
design.xml	Documents the configuration attributes of the IP in IP-XACT 2014 format.
rtl/<Instance Name>.v	This file provides an example RTL top file that instantiates the module.
rtl/<Instance Name>_bb.v	This file provides the synthesis black box.
misc/<Instance Name>_tmpl.v misc /<Instance Name>_tmpl.vhd	These files provide instance templates for the module.

### 3.3. Running the Functional Simulation

Running functional simulation can be performed after the IP is generated.


To run functional simulation:

1. Click the  button located on the **Toolbar** to initiate the **Simulation Wizard** shown in [Figure 3.4](#).



**Figure 3.4. Simulation Wizard**

2. Click **Next** to open the **Add and Reorder Source** window as shown in [Figure 3.5](#).



**Figure 3.5. Adding and Reordering Source**

3. Click **Next**. The **Summary** window is shown.
4. Click **Finish** to run the simulation.

**Note:** It is necessary to follow the procedure above until it is fully automated in the Lattice Radiant Software Suite. The results of the simulation in our example are provided in [Figure 3.6](#).




Figure 3.6. Simulation Waveform

## Appendix A. Resource Utilization

Table A.1 shows the resource utilization of the Barrel Shifter Module for the LIFCL-40 device, using Lattice Synthesis Engine of Lattice Radiant Software. Default configuration is used and some attributes are changed from the default value to show the effect on the resource utilization.

**Table A.1. Resource Utilization**

Configuration	Clk Fmax (MHz)*	Slice Registers	LUTs	EBRs
Default	200 MHz	113	175	0
<i>Shift Direction = Right, Reset Mode = Async, Others = Default</i>	200 MHz	113	175	0
<i>Data Width = 10, Maximum Number of Shifts = 9, Others = Default</i>	200 MHz	32	34	0
<i>Enable Input Register = Unchecked, Enable Pipeline Register = Unchecked, Enable Output Register = Unchecked, Others = Default</i>	N/A	0	175	0

**\*Note:** Fmax is generated when the FPGA design only contains Barrel Shifter Module and the target frequency is 200 MHz. These values may be reduced when user logic is added to the FPGA design.

## References

For complete information on Lattice Radiant Project-Based Environment, Design Flow, Implementation Flow and Tasks, as well as on the Simulation Flow, see the [Lattice Radiant Software 2.0 User Guide](#).



## Technical Support Assistance

Submit a technical support case through [www.latticesemi.com/techsupport](http://www.latticesemi.com/techsupport).

## Revision History

### Document Revision 1.0, Lattice Radiant SW version 2.0, February 2020

Section	Change Summary
All	Initial release.



[www.latticesemi.com](http://www.latticesemi.com)