



FPGA AI Firmware Pipeline

User Guide

FPGA-UG-02229-1.0

November 2024

Disclaimers

Lattice makes no warranty, representation, or guarantee regarding the accuracy of information contained in this document or the suitability of its products for any particular purpose. All information herein is provided AS IS, with all faults, and all associated risk is the responsibility entirely of the Buyer. The information provided herein is for informational purposes only and may contain technical inaccuracies or omissions, and may be otherwise rendered inaccurate for many reasons, and Lattice assumes no obligation to update or otherwise correct or revise this information. Products sold by Lattice have been subject to limited testing and it is the Buyer's responsibility to independently determine the suitability of any products and to test and verify the same. LATTICE PRODUCTS AND SERVICES ARE NOT DESIGNED, MANUFACTURED, OR TESTED FOR USE IN LIFE OR SAFETY CRITICAL SYSTEMS, HAZARDOUS ENVIRONMENTS, OR ANY OTHER ENVIRONMENTS REQUIRING FAIL-SAFE PERFORMANCE, INCLUDING ANY APPLICATION IN WHICH THE FAILURE OF THE PRODUCT OR SERVICE COULD LEAD TO DEATH, PERSONAL INJURY, SEVERE PROPERTY DAMAGE OR ENVIRONMENTAL HARM (COLLECTIVELY, "HIGH-RISK USES"). FURTHER, BUYER MUST TAKE PRUDENT STEPS TO PROTECT AGAINST PRODUCT AND SERVICE FAILURES, INCLUDING PROVIDING APPROPRIATE REDUNDANCIES, FAIL-SAFE FEATURES, AND/OR SHUT-DOWN MECHANISMS. LATTICE EXPRESSLY DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY OF FITNESS OF THE PRODUCTS OR SERVICES FOR HIGH-RISK USES. The information provided in this document is proprietary to Lattice Semiconductor, and Lattice reserves the right to make any changes to the information in this document or to any products at any time without notice.

Inclusive Language

This document was created consistent with Lattice Semiconductor's inclusive language policy. In some cases, the language in underlying tools and other items may not yet have been updated. Please refer to Lattice's inclusive language [FAQ 6878](#) for a cross reference of terms. Note in some cases such as register names and state names it has been necessary to continue to utilize older terminology for compatibility.

Contents

Contents	3
Abbreviations in This Document.....	4
1. Introduction.....	5
2. Installation.....	5
2.1. Requirements.....	5
2.1.1. Hardware.....	5
2.1.2. Software.....	5
2.1.3. Binaries.....	5
2.2. Host Computer Setup.....	5
2.3. CrossLink-NX-33 VVML Board Setup.....	6
2.3.1. Connectors Setup.....	6
2.3.2. Programming the SPI Flash Memory.....	7
3. Running the Pipeline.....	11
4. The Pipeline Output.....	12
4.1. Video.....	12
4.2. Output Data.....	12
4.2.1. Data Format.....	12
4.3. Visualizing the Pipeline Output.....	14
Reference.....	15
Technical Support Assistance.....	16
Revision History.....	17

Figures

Figure 2.1. Crosslink-NX-33 VVML Board.....	6
Figure 2.2. Radiant Programmer New Project Window.....	7
Figure 2.3. Radiant Programmer Main Window.....	7
Figure 2.4. Radiant Programmer Device Properties Windows.....	8
Figure 2.5. Radiant Programmer Device Properties Window – CrossLink-NX-33 VVML Board Configuration.....	9
Figure 2.6. Radiant Programmer Device Properties Window – CrossLink-NX-33 VVML Configuration Done.....	10

Tables

Table 4.1. Pipeline Output Format.....	12
Table 4.2. Output Data Field Format.....	12
Table 4.3. Output Person Data Field Format.....	13
Table 4.4. Output Person Face Format.....	13
Table 4.5. Output Ideal Person Format.....	14

Abbreviations in This Document

A list of abbreviations used in this document.

Abbreviation	Definition
PMOD	Peripheral MODule interface
EVE	Edge Vision Engine
TTL	Transistor-Transistor Logic
VVML board	Voice and Vision Machine Learning Board
USB	Universal Serial Bus

1. Introduction

This document provides instructions to setup and use the 3D head pose pipeline on Lattice CrossLink™-NX33 VVML board. The 3D head pose pipeline is an embedded solution which detects persons visible in the board's camera field of view. The information reported by the pipeline includes position and pose of the detected persons' bodies, faces, distance to the camera and identification status.

2. Installation

2.1. Requirements

2.1.1. Hardware

- Host computer with at least two USB ports, one should be a USB3 port.
- [Lattice CrossLink-NX-33 VVML board](#)
- USB3 A to USB3 Micro-B cable
- USB2 A to USB2 Micro-B cable
- The USB to TTL adapter able to operate at 3.3V levels, for example refer the [SH-U09C USB to TTL Adapter](#)
- Long pins break-away headers, double sided

2.1.2. Software

The Radiant Programmer can be downloaded from the [Lattice Radiant Software](#). Refer the direct links:

- [Windows](#)
- [Linux](#)

2.1.3. Binaries

VVML NX33 board SPI Flash memory image binary: `vvm_l_nx33_3d_head_pose_image.bin`

2.2. Host Computer Setup

- Install Radiant programmer on the host computer.

Ensure that your USB to TTL adapter is recognized as a COM port by connecting it to the host computer. It does not need to be connected to the CrossLink-NX-33 VVML board for your operating system to detect it. Once you have confirmed detection, unplug the adapter.

2.3. CrossLink-NX-33 VVML Board Setup




Figure 2.1. Crosslink-NX-33 VVML Board

2.3.1. Connectors Setup

1. Insert the pin headers into the PMOD sockets.
2. Adjust the voltage level of the USB to TTL adapter to 3.3V.
3. Connect the USB to TTL adapter to the VVML board using the PMOD expanded UART configuration, refer to the [PMOD interface specification document](#), Figure 2.
4. Connect the VCC pin of the USB to TTL adapter to PMOD pin 6.
5. Connect the GND pin of the USB to TTL adapter to PMOD pin 5.
6. Connect the TXD pin of the USB to TTL adapter to PMOD pin 4.
7. Connect the RXD pin of the USB to TTL adapter to PMOD pin 3.
8. Connect the USB3 A to USB3 Micro-B cable to the J8 USB 3.0 out socket.
9. Connect the USB2 A to USB2 Micro-B cable to the J2 config USB socket.

2.3.2. Programming the SPI Flash Memory

1. Connect the CrossLink-NX-33 VVML board to the host computer using the USB2 A to USB2 Micro-B cable.
2. Launch the Radiant Programmer. A new project window as shown in [Figure 2.2](#) is displayed. If the **Cable** option is not set, the CrossLink-NX-33 VVML board is not connected properly to the host computer.




Figure 2.2. Radiant Programmer New Project Window

3. Select **Create a new project from a scan**, click **OK**. [Figure 2.3](#) is displayed.




Figure 2.3. Radiant Programmer Main Window

4. Left click on line 1 to select it.
5. In the **Edit** menu, select **Device Properties**.
6. The Device Properties windows as shown in [Figure 2.4](#) is displayed.




Figure 2.4. Radiant Programmer Device Properties Windows

7. Set **Target Memory** to **External SPI Flash Memory (SPI FLASH)**. Set all other options as shown in [Figure 2.5](#).




Figure 2.5. Radiant Programmer Device Properties Window – CrossLink-NX-33 VVML Board Configuration

8. Set the **Programming file** field to `vvm_l_nx33_person_detection_image.bin` as shown in [Figure 2.6](#).




Figure 2.6. Radiant Programmer Device Properties Window – CrossLink-NX-33 VVML Configuration Done

9. Click **OK**.
10. In the **Run** menu, select **Program Device**. Note that programming can take several minutes.
11. The output window displays a successful completion message. Otherwise, check the connection between the CrossLink-NX-33 VVML board and the host computer and try again.
12. Disconnect the board from the host computer.

3. Running the Pipeline

Once your board is properly set up, the pipeline will run automatically when the CrossLink-NX-33 VVML board is powered up. The board can be powered up by plugging it to the host computer through the USB3 A to USB3 Micro-B cable, the USB2 A to USB2 Micro-B cable or the USB to TTL adapter assuming it is properly connected to the board. When the pipeline is running, the LEDs on the board should all be lit, with LED D10 blue and all others green.

4. The Pipeline Output

4.1. Video

The pipeline transmits the camera video feed via USB3. To capture the video signal on the host computer, connect the CrossLink-NX-33 VVML board using a USB3 A to USB3 Micro-B cable. The board will be recognized as an FX3 camera. You can use any compatible application, such as the Windows Camera App or VLC, to capture the video feed.

4.2. Output Data

The pipeline transmits information about detected individuals via UART. To capture this data, connect the CrossLink-NX-33 VVML board to the host computer using the USB to TTL adapter, ensuring it is properly connected to the board as described in [section 2.3.1](#).

4.2.1. Data Format

The pipeline binary output must be interpreted properly. The following tables describe the format used.

4.2.1.1. Data Packet Structure

[Table 4.1](#) describes the overall data packet structure.

Table 4.1. Pipeline Output Format

Name	Offset from previous field, in bytes	Size, in bytes	Value	Comment
Start flag	0	1	0x7e	—
Data length	1	2	0-65536	Length of the data part of the packet only.
Data	2	0-65536		Refer 4.2.1.2
Fletcher's checksum	0-65536	2	0-65536	The checksum is computer on the Data part only.

All packets start with a flag. The data length refers only to the data field, excluding the start flag, the data length itself, and the checksum. We utilize Fletcher's checksum to ensure data integrity, which is calculated solely on the data, without including the start flag and data length. The host computer should capture the data field, compute its Fletcher's checksum, and compare it with the checksum sent by the pipeline. If the two checksums do not match, the data should be discarded.

4.2.1.2. Data Field Format

Table 4.2. Output Data Field Format

Name	Offset from previous entry	Size, in bytes	Value	Unit	Comment
Number of persons	0	4	0-4294967296	NA	Interpret as unsigned int32
Person 0 data	4	Variable	Variable	NA	Refer 4.2.1.3
Person 1 data	4	Variable	Variable	NA	Refer 4.2.1.3
Person 2 data	4	Variable	Variable	NA	Refer 4.2.1.3
Person 3 data	4	Variable	Variable	NA	Refer 4.2.1.3
Person 4 data	4	Variable	Variable	NA	Refer 4.2.1.3
Ideal user data	4	Variable	Variable	NA	Refer 4.2.1.5

Note: The actual number of person data fields depends on the value of the number of persons' field. If this number is 0, there's no person data field.

4.2.1.3. Person Data Field Format

Table 4.3. Output Person Data Field Format

Name	Offset from previous entry	Size, in bytes	Value	Unit	Comment
Person body bounding box confidence	0	4	0-100, with two digits precision	NA	Interpret as signed int32, then divide by 1024
Person body bounding box left	4	4	-2147483648 to 2147483647	Pixels from the left edge of the image	Interpret as signed int32
Person body bounding box top	4	4	-2147483648 to 2147483647	Pixels from the top edge of the image	Interpret as signed int32
Person body bounding box right	4	4	-2147483648 to 2147483647	Pixel from the left edge of the image	Interpret as signed int32
Person body bounding box bottom	4	4	-2147483648 to 2147483647	Pixel from the top edge of the image	Interpret as signed int32
Person body pose	4	4	FRONT, SIDE, BACK	NA	Interpret as unsigned int32. Value 0 means FRONT, 1 means SIDE and 2 means BACK
Person distance from camera	4	4	0-4294967296	cm	Interpret as unsigned int32

4.2.1.4. Person Face Data Field

Table 4.4. Output Person Face Format

Name	Offset from previous entry	Size, in bytes	Value	Unit	Comment
Person's face bounding box confidence	0	4	0-100	NA	Interpret as signed int32 then divide by 1024
Person's face bounding box left	4	4	-2147483648 to 2147483647	Pixels from the left edge of the image	Interpret as signed int32
Person's face bounding box top	4	4	-2147483648 to 2147483647	Pixels from the top edge of the image	Interpret as signed int32
Person's face bounding box right	4	4	-2147483648 to 2147483647	Pixels from the left edge of the image	Interpret as signed int32
Person's face bounding box bottom	4	4	-2147483648 to 2147483647	Pixels from the top edge of the image	Interpret as signed int32
Person's face yaw angle	4	4	-180 to 180	Degrees	Interpret as signed int32 then divide by 1024
Person face pitch angle	4	4	-180 to 180	Degrees	Interpret as signed int32 then divide by 1024

The fields related to a person's face are accessible only when the Person face availability field is set to True.

4.2.1.5. Ideal Person Data

Table 4.5. Output Ideal Person Format

Name	Offset from previous entry	Size, in bytes	Value	Unit	Comment
Ideal person index	0	4	0-4	NA	Interpret as signed int32. Indicates which user to is the ideal one. This shouldn't be equal or greater than the number of detected persons
Ideal person identification status	4	4	REGISTERED, UNREGISTERED, UNKNOWN	NA	Interpret as signed int32. Value 0 means REGISTERED, 1 means UNREGISTERED, 2 means UNKNOWN.

Note: Ideal person's data is only available if at least one person was detected.

4.3. Visualizing the Pipeline Output

The EVE tool can be used to visualize the Person Detection pipeline output overlaid over the camera image output from the USB3 socket of the CrossLink-NX-33 VVML board. For this to work, the CrossLink-NX-33 VVML board must be connected to the host computer with the USB3 A to USB3 Micro-B cable and the USB to TTL adapter. Follow instructions in the EVE documentation to use this feature.

Reference

- [CrossLink-NX-33 Voice and Vision Machine Learning board](#)
- [Lattice Radiant webpage](#), with links to the Radiant Programmer installers
- [Radiant Programmer installer for Windows](#)
- [Radiant Programmer installer for Linux](#)
- [PMOD Specification](#)
- [Fletcher's checksum Wikipedia page](#)
- [Lattice Insights](#) for Lattice Semiconductor training courses and learning plans

Technical Support Assistance

Submit a technical support case through www.latticesemi.com/techsupport.

For frequently asked questions, refer to the Lattice Answer Database at www.latticesemi.com/Support/AnswerDatabase.

Revision History

Revision 1.0, November 2024

Section	Change Summary
All	Initial release.



www.latticesemi.com