



Lattice Propel 2022.1 Builder

User Guide

FPGA-UG-02177-1.0

November 2022

Disclaimers

Lattice makes no warranty, representation, or guarantee regarding the accuracy of information contained in this document or the suitability of its products for any particular purpose. All information herein is provided AS IS, with all faults and associated risk the responsibility entirely of the Buyer. Buyer shall not rely on any data and performance specifications, or parameters provided herein. Products sold by Lattice have been subject to limited testing and it is the Buyer's responsibility to independently determine the suitability of any products and to test and verify the same. No Lattice products should be used in conjunction with mission- or safety-critical or any other application in which the failure of Lattice's product could create a situation where personal injury, death, severe property, or environmental damage may occur. The information provided in this document is proprietary to Lattice Semiconductor, and Lattice reserves the right to make any changes to the information in this document or to any products at any time without notice.

Contents

Glossary	9
1. Introduction	10
1.1. Purpose	10
1.2. Audience	10
2. Lattice Propel Builder Design Flows	11
2.1. Builder Environment	11
2.2. Project Design Flow	12
2.2.1. Creating a New SoC Project	12
2.2.2. Creating Template SoC Project	16
2.2.3. Opening a SoC Existing Project	21
2.2.4. Adding Modules	22
2.2.5. Adding Glue Logic	26
2.2.6. Undo/Redo	33
2.2.7. Modifying the Project Settings	33
2.2.8. Working with the Schematic View	35
2.2.9. Connecting Modules	45
2.2.10. Creating Top-Level Ports	54
2.2.11. Adjusting Address Spaces	57
2.2.12. Validating the Design	58
2.2.13. Generating the RTL file	58
2.2.14. Opening Project in Diamond or Radiant	58
2.2.15. Launching SDK	62
2.3. Verification Project Design Flow	65
2.3.1. Creating a Verification Project	65
2.3.2. Switching SoC Project to Verification Project	67
2.3.3. Opening a Verification Project	68
2.3.4. Adding Modules, IP and VIPs	69
2.3.5. Working with the Schematic View	69
2.3.6. Connecting Modules	69
2.3.7. Monitoring DUT	69
2.3.8. Generating Simulation Environment	70
2.3.9. Launching Simulation	70
2.4. Advanced Usage	73
2.4.1. Supported Interface	73
2.4.2. Supported Language	73
2.4.3. Supported Hierarchical IP	73
2.4.4. Export Interface	74
2.4.5. Define Custom Template	75
2.4.6. Include Sub Sbx File	82
3. IP Packager	83
3.1. Launching IP Packager	84
3.2. Packing Custom IP Flow	84
3.2.1. Opening an IP Directory	84
3.2.2. Editing IP	87
3.2.3. Previewing IP	109
3.2.4. Packaging IP	110
3.3. Editing IP Package Files	110
3.3.1. Metadata File	110
3.3.2. Implementation RTL Files	120
3.3.3. Python Script Plugin File	121
3.3.4. Memory Map CSV File	122
4. TCL Commands	123

4.1.	sbp_design	123
4.1.1.	Open.....	123
4.1.2.	Close.....	123
4.1.3.	New	123
4.1.4.	Save	123
4.1.5.	Drc.....	124
4.1.6.	Generate	124
4.1.7.	Auto Assign Addresses	124
4.1.8.	Verify.....	124
4.1.9.	PGE.....	124
4.1.10.	Undo	125
4.1.11.	Redo.....	125
4.1.12.	Set Device	125
4.2.	Other TCL Commands.....	125
4.2.1.	sbp_add_component	125
4.2.2.	sbp_add_sbxcamp	126
4.2.3.	sbp_add_gluelogic	126
4.2.4.	sbp_create_glue_logic	126
4.2.5.	sbp_add_port.....	126
4.2.6.	sbp_modify_port	126
4.2.7.	sbp_connect_net	126
4.2.8.	sbp_connect_interface_net.....	126
4.2.9.	sbp_connect_constant.....	126
4.2.10.	sbp_connect_whitebox	127
4.2.11.	sbp_disconnect_whitebox.....	127
4.2.12.	sbp_disconnect_interface_net	127
4.2.13.	sbp_disconnect_net	127
4.2.14.	sbp_assign_addr_seg.....	127
4.2.15.	sbp_unassign_addr_seg	127
4.2.16.	sbp_assign_local_memory	127
4.2.17.	sbp_export_pins	128
4.2.18.	sbp_export_interface	128
4.2.19.	sbp_rename.....	128
4.2.20.	sbp_replace	128
4.2.21.	sbp_copy.....	128
4.2.22.	sbp_delete	129
4.2.23.	sbp_get_pins	129
4.2.24.	sbp_get_interface_pins	129
4.2.25.	sbp_get_ports.....	129
4.2.26.	sbp_get_interface_ports	129
4.2.27.	sbp_get_nets	129
4.2.28.	sbp_get_interface_nets.....	129
4.2.29.	sbp_set_property	130
4.2.30.	sbp_get_property	130
4.2.31.	sbp_report_properties	130
4.2.32.	sbp_get_components	130
Appendix A.	metadata.xsd	131
References		140
Technical Support Assistance		141
Revision History		142

Figures

Figure 2.1. Propel Builder Workbench Window	11
Figure 2.2. Create System Design – Design Information Wizard	12
Figure 2.3. Create System Design – Configure Propel Project Wizard.....	13
Figure 2.4. Specify a Device for a New SoC Project	14
Figure 2.5. Specify a Board for a New SoC Project	14
Figure 2.6. Specify a Board for a New SoC Project	15
Figure 2.7. Create System Design – Project Information Wizard	15
Figure 2.8. Propel Builder GUI Shows Empty Project	16
Figure 2.9. Create System Design – Design Information Wizard	17
Figure 2.10. Specify a Device for Template SoC Project (1).....	17
Figure 2.11. Specify a Device for Template SoC Project (2).....	18
Figure 2.12. Specify a Board for Template SoC Project (1).....	19
Figure 2.13. Specify a Board for Template SoC Project (2).....	20
Figure 2.14. Project Information Wizard	20
Figure 2.15. Propel Builder GUI showing HelloWorld Template SoC Project	21
Figure 2.16. Open Sbx Dialog.....	21
Figure 2.17. Open HelloWorld Project.....	22
Figure 2.18. IP Catalog	23
Figure 2.19. Module/IP Block Wizard – Generate Component from Module gpio Version 1.6.0	24
Figure 2.20. Module/IP Block Wizard - Configure Component from IP Gpio Version 1.6.0	24
Figure 2.21. Module/IP Block Wizard - Check Generated Result	25
Figure 2.22. Design Instance Dialog Box.....	25
Figure 2.23. Propel Builder Schematic View Shows the Module Instance	26
Figure 2.24. IP Catalog	27
Figure 2.25. Glue Logic for Concat Module	28
Figure 2.26. Schematic View Shows a Concat Module	28
Figure 2.27. Glue Logic Wizard for Equation Module.....	29
Figure 2.28. Schematic View Shows an Equation Module.....	29
Figure 2.29. Schematic View Shows the Invert Module	30
Figure 2.30. Glue Logic Wizard for Rtl Module	30
Figure 2.31. Existing Rtl Module Configuration	31
Figure 2.32. Schematic View Shows the Custom Rtl Module	31
Figure 2.33. Glue Logic Wizard for Split Module	32
Figure 2.34. Schematic View Shows Split Module	32
Figure 2.35 Design View of Device Part Number.....	33
Figure 2.36 Modify Device Info.....	34
Figure 2.37 System Builder Dialog	34
Figure 2.38 Design View of Device Part Number.....	35
Figure 2.39. Signal List of Modules	36
Figure 2.40. Select Object	37
Figure 2.41. Locate Objects	38
Figure 2.42. Duplicate a Module.....	38
Figure 2.43. Design View	39
Figure 2.44. Define Instance Dialog Box	39
Figure 2.45. Module/IP Block Wizard – Configure Component.....	40
Figure 2.46. Select Module	41
Figure 2.47. Options Dialog	42
Figure 2.48. Show Connectivity of the Module	43
Figure 2.49. Highlight an Object	43
Figure 2.50. Object Properties.....	44
Figure 2.51. Print Preview	44
Figure 2.52. Draw a Pin or a Port.....	45

Figure 2.53. Draw Nets	45
Figure 2.54. Select More than One Ports.....	46
Figure 2.55. Action Menu of Right-clicking on Blank	47
Figure 2.56. Action Menu of Connecting Ports.....	48
Figure 2.57. Select One Clock/Reset Port	49
Figure 2.58. Connecting CPU Instance Reset Output Port.....	49
Figure 2.59. Interface Type of cpu0_inst.AHBL_M1_DATA	50
Figure 2.60. Interface Connection on from CPU to Bus/Bridge instances in Schematic View	50
Figure 2.61. Interface Connection from CPU to Bus/Bridge Instances in Connect Port view.....	51
Figure 2.62. Interface connection on other instances connect back to CPU in Schematic View.....	51
Figure 2.63. Interface connection on other instances connect back to CPU in Connect Port view.....	51
Figure 2.64. Interface Type of gpio0_inst.INTR	52
Figure 2.65. Interface Type of cpu0_inst.IRQ_S0.....	52
Figure 2.66. Action Menu of Right-clicking an Input Pin.....	53
Figure 2.67. Dialog Box of Assigning Constant Value to an Input Pin	53
Figure 2.68. Create Port Dialog Box.....	54
Figure 2.69. Input Port.....	54
Figure 2.70. Output Port and Inout Port.....	54
Figure 2.71. Properties of Port.....	55
Figure 2.72. Port Direction.....	56
Figure 2.73. PortBus Direction	56
Figure 2.74. Address View	57
Figure 2.75. Edit Base Address.....	57
Figure 2.76. Memory Report	58
Figure 2.77. Diamond Project	59
Figure 2.78. Generate Programming Files	60
Figure 2.79. Radiant Project	61
Figure 2.80. Radiant Project for Project before Propel Builder 2022.1	62
Figure 2.81. Lattice Propel Launcher Wizard	62
Figure 2.82. Propel SDK GUI and C/C++ Project Wizard	63
Figure 2.83. Create C/C++ Project.....	64
Figure 2.84. Create System Design – Design Information Wizard	65
Figure 2.85. Create System Design – Propel Project Configure Wizard.....	66
Figure 2.86. Verification Project	67
Figure 2.87. Whole SoC Design	67
Figure 2.88. Propel Builder Dialog Box	68
Figure 2.89. Switching to Project Verification	68
Figure 2.90. Monitoring DUT	69
Figure 2.91. Testbench of the Verification Project	69
Figure 2.92. Testbench File Structure	70
Figure 2.93. Propel Builder – A Reminding Dialog Box	70
Figure 2.94. Simulation GUI	71
Figure 2.95. Builder Options Wizard	72
Figure 2.96. Hierarchical IP	73
Figure 2.97. Hierarchical IP Scope in Detail	74
Figure 2.98. Export Interface Example.....	74
Figure 2.99. Memory Map for ahbl_s0_inst in Address Editor	75
Figure 2.100. Export Template Configuration Page	76
Figure 2.101. Check IP Name in Design View.....	77
Figure 2.102. Check Device Supported in IP Information	77
Figure 2.103. Export Template to PropelTemplateLocal Folder	78
Figure 2.104. Template Manager Entry	78
Figure 2.105. Templates Manager Page.....	79
Figure 2.106. Import ptmp File	79

Figure 2.107. Template Manager Page.....	80
Figure 2.108. Template Manager Page – Change to New Location.....	81
Figure 2.109. Right Click on Schematic View	82
Figure 2.110. Input sbx File and Instance Name.....	82
Figure 3.1. Example Directories and Files of an IP Package.....	83
Figure 3.2. Example Directories and Files of an IP Instance Package	83
Figure 3.3. IP Packager GUI.....	84
Figure 3.4. Select Folder Dialog	85
Figure 3.5. IP Packager with IP Project Details	86
Figure 3.6. IP Packager with Meta Data Details.....	87
Figure 3.7. Meta Data View	88
Figure 3.8. Configure Basic Info	88
Figure 3.9. Warning Message of the Invalid Radiant and Propel Version	89
Figure 3.10. Preview on Parameters.....	90
Figure 3.11. Two-Level Hierarchy to Categorize Parameters	91
Figure 3.12. IP Preview Showing Two-level Hierarchy in Parameters	92
Figure 3.13. Right-click Menu of Parameters in the Meta Data View	93
Figure 3.14. Group1 Added to Tab1	93
Figure 3.15. NewParam1 Added to Group1	94
Figure 3.16. Rename a Parameter	94
Figure 3.17. Configure a Parameter.....	95
Figure 3.18. Three Port Types.....	97
Figure 3.19. Right-click Menu of the IN Port	97
Figure 3.20. Add inferred ports to meta data Wizard	98
Figure 3.21. Rename an IN Port.....	98
Figure 3.22. Configure an IN Port	99
Figure 3.23. Right-click Menu of an Interface.....	100
Figure 3.24. Rename Interface	100
Figure 3.25. Configure an Interface	101
Figure 3.26. Right-click Menu of a Memory Map	102
Figure 3.27. Generate New Memory Map.....	103
Figure 3.28. IP Packager with Design File Details	104
Figure 3.29. IP Packager with Test Bench Details	105
Figure 3.30. IP Packager with Misc Details	106
Figure 3.31. IP Packager with Doc Assistant Details	107
Figure 3.32. Configure Doc Assistant.....	108
Figure 3.33. IP Preview Shows Configuration for IP Module	109
Figure 3.34. IP Packager Pops up Error Message.....	109
Figure 3.35. IP Packager Pops up Successful Packaging Message	110
Figure 3.36. Example XML of Metadata Layout.....	110
Figure 3.37. Example of busInterface Node	116
Figure 3.38. Example of addressSpaces Node	117
Figure 3.39. Example of memoryMaps Node	118
Figure 3.40. Example of componentGenerators Node	119
Figure 3.41. Example of Xinclude Usage.....	120
Figure 3.42. Example of Specifying Lib for VHDL	120
Figure 3.43. Template of Plugin File	121
Figure 3.44. Example of Memory Map CSV File.....	122
Figure 4.1. Tcl Console	123

Tables

Table 3.1. Details of Parameter Property	95
Table 3.2. Details of Port Property.....	99
Table 3.3. Child Nodes of General Node.....	111
Table 3.4. Attributes of Setting Nodes.....	112
Table 3.5. Attributes of Port Nodes	114
Table 3.6. Elements in estimatedResources Node	119

Glossary

A list of words or terms specialized in this document.

Glossary	Definition
BSP	Board Support Package, the layer of software containing hardware-specific drivers and libraries to function in a particular hardware environment.
CPU	Central Processing Unit.
CSV	Comma Separated Values file.
DRC	Design Rule Check.
DUT	Design Under Test.
ESI	Previous name of Propel.
FPGA	Field Programmable Gate Array.
GUI	Graphic User Interface.
HDL	Hardware Description Language.
HSM	Hardware Security Module.
IDE	Integrated Development Environment.
IP-XACT	An XML format that defines and describes electronic components and their designs.
LHS	Left Hand Side.
LSB	Least Significant Bit.
MSB	Most Significant Bit.
Perspective	A group of views and editors in the Workbench window.
PGE	Package Generate Engine
Programmer	A tool can program Lattice FPGA SRAM and external SPI Flash through various interfaces, such as JTAG, SPI, and I ² C.
RHS	Right Hand Side.
RISC-V	A free and open instruction set architecture (ISA) enabling a new era of processor innovation through open standard collaboration.
SBX	The files that store the spatial index of the features
SDK	Embedded System Design and Develop Kit. A set of software development tools that allows the creation of applications for software package on the Lattice embedded platform.
SoC	System on Chip. An integrated circuit that integrates all components of a computer or other electronic systems.
SRAM	Static Random Access Memory.
TCL	Tool Command Language.
UFM	User Flash Memory.
VIP	Verification IP.
Workspace	The directory where stores your work, it is used as the default content area for your projects as well as for holding any required metadata.
Workbench	Refers to the desktop development environment in Eclipse IDE platform.

1. Introduction

Lattice Propel™ 2022.1 Builder is a graphical tool used to assemble complex System-on-Chip (SoC) modules which can be used in the supported Lattice FPGA devices. These modules and/or IP can be assembled and connected easily by simply dragging and dropping the modules and/or IP into the Schematic Window.

1.1. Purpose

Embedded system solutions play an important role in FPGA system design allowing you to develop the software for a processor in an FPGA device. It provides flexibility for you to control various peripherals from a system bus.

To develop an embedded system on an FPGA, you need to design the System on Chip (SoC) with an embedded processor. Lattice Propel Builder helps you develop your system with a RISC-V processor, peripheral IP, and a set of tools by a simple drag-and-drop.

The purpose of this document is to introduce Lattice Propel 2022.1 Builder tool and design flow to help you quickly get started to build a small demo system. You can also find the recommended flows of using Lattice Propel Builder in this document.

1.2. Audience

The intended audience for this document includes embedded system designers and embedded software developers using Lattice MachXO3D, MachXO3L, MachXO3LF, MachXO2, LIFCL, LFD2NX, LFMNX, LFCPNX, LFMXO5, and LAV-AT devices. The technical guidelines assume readers have expertise in the embedded system area and FPGA technologies.

2. Lattice Propel Builder Design Flows

The Propel Builder design flow includes creating a SoC project design flow, and verification design flow, which are discussed in detail in the following sections.

2.1. Builder Environment

After Propel 2022.1 is installed, you can launch the stand-alone Propel Builder by double-clicking the Builder icon to launch Builder. Refer to the [Lattice Propel 2022.1 Installation for Windows User Guide \(FPGA-AN-02056\)](#) for details on the installation. After the Propel Builder is launched, a single workbench window is displayed. The workbench contains Menu, Toolbar, Design View, IP catalog, Schematic view, address mapping, Start Page, and TCL console. [Figure 2.1](#) shows the workbench with opening a project.

1. Menu bar
2. Toolbar
3. IP Catalog and Design View
4. Schematic View, Address Mapping, and Start Page
5. TCL Console




Figure 2.1. Propel Builder Workbench Window

2.2. Project Design Flow

2.2.1. Creating a New SoC Project

1. Choose **File** >  **New Design** from the Lattice Propel Builder Menu bar. The Create System Design – Design Information wizard opens (Figure 2.2).




Figure 2.2. Create System Design – Design Information Wizard

2. The default Project Type is displayed in the **Type** field.
 - You can select **SoC Project** from the drop-down menu, if you need to create a SoC project.
 - You can select **SoC Verification** from the drop-down menu, if you need to create a verification project. Refer to the [Verification Project Design Flow](#) section for more details.
3. Enter the desired project name in the **Name** field.
4. (Optional) The default location is shown in the **Location** field. Use the **Browse...** option to change the project workspace location.
5. Click **Next**. The Create System Design - Configure Propel Project wizard opens (Figure 2.3).




Figure 2.3. Create System Design – Configure Propel Project Wizard

6. (Optional) The default *Verilog* is displayed in the **Language** field. Use the drop-down menu to change the default language.
7. Specify a device or a board.
 - To specify a device for your new SoC project, use the drop-down menu to select desired device information (Family, Device, Package and Speed), and select **Empty Project** in the **Templates** field (Figure 2.4).




Figure 2.4. Specify a Device for a New SoC Project

- Or, to specify a board for a new SoC project, check the **Board** option (Figure 2.6).




Figure 2.5. Specify a Board for a New SoC Project

- The Configure Propel Project wizard is shown (Figure 2.7). From the **Board Select** area, select the desired board, such as CertusPro-NX Evaluation.




Figure 2.6. Specify a Board for a New SoC Project

- Click **Next**. The Project Information wizard opens (Figure 2.7).




Figure 2.7. Create System Design – Project Information Wizard

- Check and confirm the project information.
- Click **Finish**. Propel Builder GUI opens (Figure 2.8).




Figure 2.8. Propel Builder GUI Shows Empty Project

2.2.2. Creating Template SoC Project

Templates are customized with common-used programs as well as pre-defined family, device, package, speed and operating condition. This HelloWorld template is programmed to run HelloWorld demo. You can make changes based on this template.

1. Choose **File** > **New Design** from the Lattice Propel Builder Menu bar. The Create System Design wizard (Figure 2.9).opens




Figure 2.9. Create System Design – Design Information Wizard

2. The default Project Type is displayed in the **Type** field. Select **SoC Project** from the drop-down menu.
3. Enter a project name in the **Name** field, such as HelloWorld.
4. (Optional) The default location is shown in the **Location** field. Use the **Browse...** option to change the project workspace location.
5. Click **Next**.
6. From the Configure Propel Project wizard, you can specify a device or a board for a Template SoC project (Figure 2.10).




Figure 2.10. Specify a Device for Template SoC Project (1)

- To specify a device for your new Template SoC project, use the drop-down menu to select desired device information (Family, Device, Package and Speed), and select **Hello World Project** from the Templates field (Figure 2.11).

Note:

Different device families are supported and available in Radiant or Diamond software accordingly.

- Available in Radiant software only: LFCPNX (CertusPro-NX)/LFD2NX (Certus-NX)/LFMXO5 (MachXO5-NX)/LIFCL (CrossLink-NX).
- Available in Diamond software only: LFMNX/MachXO2/MachXO3D/MachXO3L/MachXO3LF.




Figure 2.11. Specify a Device for Template SoC Project (2)

- Or, to specify a board for a new Template SoC project, check the **Board** option (Figure 2.12).




Figure 2.12. Specify a Board for Template SoC Project (1)

7. The Configure Propel Project wizard is shown (Figure 2.13). From the **Board Select** area, select the desired board, such as CertusPro-NX Evaluation.
8. Select a desired template from the **Templates** area, such as Hello World Project (Figure 2.13).




Figure 2.13. Specify a Board for Template SoC Project (2)

9. Click **Next**. The Project Information wizard opens (Figure 2.14).




Figure 2.14. Project Information Wizard

10. Check and confirm the project information.

11. Click **Finish**. Propel Builder GUI opens (Figure 2.16).




Figure 2.15. Propel Builder GUI showing HelloWorld Template SoC Project

2.2.3. Opening a SoC Existing Project

1. Choose **File** >  **Open Design** from Propel Builder GUI Menu, or Click **Open Design** icon  from Propel Builder Toolbar. The Open sbx dialog opens (Figure 2.16).




Figure 2.16. Open Sbx Dialog

2. Browse to find the default project workspace folder or your own project workspace folder. Choose the sbx file, such as HelloWorld.sbx (Figure 2.17).




Figure 2.17. Open HelloWorld Project

3. Click **Open**. The Builder GUI shows the SoC design.

Note: Choose **File > Recent Designs** from Propel Builder GUI Menu. You can quickly open a most recently closed project.

2.2.4. Adding Modules

After starting a Propel Builder project, you can add modules by dragging them from the IP Catalog view to the Schematic view. The IP Catalog view comes with a large variety of modules for common use and some glue logic modules as well, which can be found from the **IP on Local** tab (Figure 2.18). Click the **IP on Server** tab to find and download more modules for specialized use.

1. (Optional) From the Propel Builder GUI **IP Catalog** area (Figure 2.18), choose the **IP on Server** tab. Select a desired IP. Click the  **Install** button. After the IP is installed successfully, the new IP can be shown in the **IP on Local** tab.




Figure 2.18. IP Catalog

- From the **IP on Local** tab, select a desired IP, such as GPIO. Double-click the IP module or drag and drop the IP module to the **Schematic** view. A Module/IP Block wizard pops up (Figure 2.19).




Figure 2.19. Module/IP Block Wizard – Generate Component from Module gpio Version 1.6.0

3. Enter a component name in the **Component name** area, such as gpio0. Click **Next**. Module/IP Block Wizard shows the **Configure Component from IP gpio Version 1.6.0** page (Figure 2.20).




Figure 2.20. Module/IP Block Wizard - Configure Component from IP Gpio Version 1.6.0

4. (Optional) Click the **Value** field. You can enter a desired value for a property, check the checkbox to select a property, or select a desired value from the dropdown menu for a property in the **Value** area. By changing the value, the properties are thus configured. The property in gray is not configurable.
5. Click **Generate**. Module/IP Block wizard shows the Check Generated Result page (Figure 2.21).




Figure 2.21. Module/IP Block Wizard - Check Generated Result

6. Select **Insert to project** (Figure 2.21) at the bottom of the Check Generate Result wizard.
7. Click **Finish**. The **Define Instance** dialog box opens (Figure 2.22).




Figure 2.22. Design Instance Dialog Box

8. (Optional) Change the instance name, if desired. Space and special characters are not allowed.
9. Click **OK**. The schematic block for the module appears in the **Schematic** view (Figure 2.23).




Figure 2.23. Propel Builder Schematic View Shows the Module Instance

2.2.5. Adding Glue Logic

Propel 2022.1 builder supports glue logic modules as well as IP modules. You can add glue logic modules by dragging them from the IP Catalog view (Figure 2.24) to the Schematic view.




Figure 2.24. IP Catalog

- Concat
 - a. From the IP Catalog, select the **concat** module. Double-click the concat module or drag and drop concat module to the Schematic view. A Glue Logic wizard ([Figure 2.25](#)) pops up.




Figure 2.25. Glue Logic for Concat Module

- b. Click the **RHS** field to change the default right-hand side bus width to a desired one. Click the **LHS** field to change the default left-hand side bus width to a desired one. Click the **Add** button to add LHS (Left-hand Side). Click the **Remove** button to remove LHS (Left-hand Side). You can only add or remove LHS but not RHS. LHS and RHS are thus configured.
- c. Click **OK**. The schematic block for the concat module in red appears in the Schematic view ([Figure 2.26](#)).




Figure 2.26. Schematic View Shows a Concat Module

- Equation
 - a. From the IP Catalog, select the **equation** module. Double-click the equation module, or drag and drop the equation module to the Schematic view. A Glue Logic wizard ([Figure 2.27](#)) pops up.




Figure 2.27. Glue Logic Wizard for Equation Module

- b. Click the **Module Name** field to change the default value to a desired name. Click the **Expression** field to change the default expression to a desired one. The expression supports and (&), or (|), negation (!). The module name and expression are thus configured.
- c. Click **OK**. The schematic block for the equation module in red appears in the Schematic view (Figure 2.28).




Figure 2.28. Schematic View Shows an Equation Module

- Invert
 - a. From the IP Catalog, select the **invert** module. Double-click the invert module or drag and drop invert module to the Schematic view. The schematic block for the invert module in red appears in the Schematic view (Figure 2.29).




Figure 2.29. Schematic View Shows the Invert Module

- Rtl
 - a. From the IP Catalog, select the **rtl** module. Double-click the rtl module or drag and drop the rtl module to the Schematic view. A Glue Logic wizard (Figure 2.30) pops up.




Figure 2.30. Glue Logic Wizard for Rtl Module

- b. You can edit your own rtl module in the **Rtl** area by entering the rtl module function.

- c. Or you can use an existing rtl module by checking the **Use Existing File** checkbox. After checking the **Use Existing File** checkbox (Figure 2.31), browse to find the existing RTL module file path from the **Path** field. And, check the **CopyToDesign** checkbox, if you want to copy the rtl module to the design.




Figure 2.31. Existing Rtl Module Configuration

- d. Click **OK**. The schematic block for the rtl module in red appears in the Schematic view (Figure 2.32).




Figure 2.32. Schematic View Shows the Custom Rtl Module

Note: Currently, Rtl Module only supports Verilog HDL.

- Split
 - a. From the IP Catalog, select the **split** module. Double-click the split module, or drag and drop the split module to the Schematic view. A Glue Logic wizard (Figure 2.33) pops up.




Figure 2.33. Glue Logic Wizard for Split Module

- b. Click **LHS** field to change the default left-hand side bus widths to a desired one. Click **RHS** field to change the default right-hand side bit width to a desired one. Click the button to add an RHS. Click the button to remove an RHS. You can only add or remove RHS but not LHS. LHS and RHS are thus configured.
- c. Click **OK**. The schematic block for the split module in red appears in the Schematic view (Figure 2.34).




Figure 2.34. Schematic View Shows Split Module

2.2.6. Undo/Redo

Propel 2022.1 Builder supports one-level undo/redo. You can click the Undo icon from Propel Builder Toolbar to go back to last action. Click the Redo icon from Propel Builder Toolbar to recover last undo action.

- Undo: Choose **Edit** >  **Undo** from the Lattice Propel Builder Menu bar. Or, click the **Undo** icon  from Propel Builder GUI Toolbar.
- Redo: Choose **Edit** >  **Redo** from the Lattice Propel Builder Menu bar. Or, click the **Redo** icon  from Propel Builder Toolbar.

Note: Currently, Propel 2022.1 Builder only supports single undo/redo.

2.2.7. Modifying the Project Settings

Propel 2022.1 Builder supports changing the projects settings. You can modify the device, package, speed and operating conditions by double clicking the device part number from the Design View.

1. Double click the device part number from the Design View ([Figure 2.35](#)), the Modify Device Info wizard pops up ([Figure 2.36](#)).





Figure 2.35 Design View of Device Part Number

- Use the drop-down menu to choose the desired device in **Device** filed in the Modify Device Info wizard (Figure 2.36). Use the drop-down menu to change the package, speed and operating condition in **Package, Speed, Operating Condition** filed.




Figure 2.36 Modify Device Info

- Click **OK**. The System Builder dialog (Figure 2.37) pops up to show the warning message about configuring all IP.




Figure 2.37 System Builder Dialog

- Click **Yes** to configure all IP in current project. The new device part number shows in Design View (Figure 2.38).




Figure 2.38 Design View of Device Part Number

2.2.8. Working with the Schematic View

You can make changes in the Schematic view including automatic layout to clean up the display, moving, resizing, renaming blocks manually, highlighting objects and zooming the display in and out.

- To view signal list of block:

Click the plus sign  of the desired block to see what signals it contains. The plus sign changes to a negative sign  and shows the signal list as shown in [Figure 2.39](#). Click the negative sign  to close the expanded bus. The schematic returns to the previous form.




Figure 2.39. Signal List of Modules

- To select one or more objects:
Select one object or more objects in one of the following ways:
 - Click on the object in the Schematic view. The selected object turns to red (Figure 2.40).




Figure 2.40. Select Object

- Ctrl-click or Shift-click in the Schematic view to select more than one objects.
 - Click the Area_select icon  from the Propel Builder Toolbar. Click and drag to draw a selection rectangle around the modules and ports in the Schematic view. Click the icon again to turn off the Area_select mode.
 - From the Schematic view, right-click and choose Select All or press Ctrl-A to select all the objects.
- Note:** Ctrl-click or Shift-click on the object in the Schematic view can also de-select the object while leaving the others selected.
- To re-arrange the schematic:

Propel Builder allows re-arranging the objects in the schematic view. You can re-arrange modules and the ports. Drag objects to re-arrange the schematic. Propel Builder has rules for placing objects to adjust the schematic in an organized arrangement.

 - Select the desired modules (one or more modules can be dragged at the same time) or ports (one or more ports can be dragged at the same time).
 - Click on the selected items and drag it to the desired location.
 - Release the mouse button.

Note: The selected objects can be moved to the specified location, or as near as the rules allow. Other objects in the schematic can also be moved to accommodate the selected objects' new location.
 - To bring selected objects to the center of the Schematic view using the Locate Object mode:
 - Click the **Locate Object** icon  from the Propel Builder Toolbar. The background turns to dark gray.
 - Select the object in the List view of the Design View. The selected object is in the center of the Schematic View (Figure 2.41).




Figure 2.41. Locate Objects

- To automatically simplify the layout:
Right-click anywhere in the Schematic view and choose **Relayout**.
- To duplicate a module:

Select the desired module and click **Clone** . Or right-click on the module and choose **Clone** . A copy of the schematic block appears with a new instance name (Figure 2.42).




Figure 2.42. Duplicate a Module

- To restore a deleted module:
 - In the List view of the Design View (Figure 2.43), go to the Components folder. The deleted module can still be found in the List view in plain text. Those not deleted are shown in bold-faced text.





Figure 2.43. Design View

- Right-click on the desired component and choose **Instantiate**. The Define Instance dialog box (Figure 2.44) open.




Figure 2.44. Define Instance Dialog Box

- c. Enter a name for the new instance.
- d. Click **OK**. The module appears in the Schematic view and the List view of Design Info, and the component name is bold-faced.
- To reconfigure a module:
 - a. Double-click the module, or right-click the module. Choose **Reconfig**. The Module/IP Block wizard (Figure 2.45) opens.




Figure 2.45. Module/IP Block Wizard – Configure Component

- b. Configure component (including General property, Main Settings and Mater Priority Settings) at Configure IP table in the Module/IP Block Wizard. Click **Generate** to generate the module as usual. The schematic block for the module changes to match the new configuration.
- Note:** For a SoC design, if the init file (mem file) of System Memory module instance is updated in a C project, the initialization section of the system memory module instance should be re-configured. Or, use the ECO flow to update the information. Refer to the [Diamond online help](#) for more on how to use an ECO flow.
- To resize module blocks:
 - a. Select the desired module block. The block is highlighted in red with black corners (Figure 2.46).




Figure 2.46. Select Module

- b. Click and drag one of the corners to change the size and shape of the block.
- c. Release the mouse button. All the other objects move to make room for this block.

Note: Right-click the module block and choose **Unresize Instance** to restore the size of the module block.

There are a variety of methods to zoom within the Schematic view, including toolbar commands and dragging in the Schematic view.

The following commands are available from the Propel Builder Toolbar.

- Zoom In (Ctrl++)  — enlarges the view of the entire layout.
- Zoom Out (Ctrl+-)  — reduces the view of the entire layout.
- Zoom Fit  — reduces or enlarges the entire layout so that it fits inside the window.
- Zoom To  — enlarges the size of one or more selected objects on the layout and fills the window with selection.

Note: The mouse wheel provides a finer zoom control by rolling the mouse wheel forward to zoom in and backward to zoom out while pressing the Ctrl key.

- To zoom by holding the mouse button and dragging.
 - To zoom to fit the window, drag up and to the left. The image adjusts to fill the window.
 - To zoom out, drag up and to the right. The dragging distance determines the amount of zoom. The image is reduced and centered in the window.
 - To zoom in, drag down and to the left. The dragging distance determines the amount of zoom. The image is enlarged and centered in the window.
 - To zoom in in a specific area, start at the upper-left corner of the area and drag to the lower-right corner of the area. The area that dragging across is adjusted to fill the window.

Note: Make sure that the **Area_select** icon  is not selected in the Toolbar. If you need to use Area_select and zoom by dragging frequently, choose **Design > Options** from Propel Builder menu bar. The Options Dialog opens (Figure 2.47). Select **Use right mouse button for zooming actions** and click **OK**. Then you can select an instance

using the left mouse button, zoom in or zoom out using the right mouse button, and the **Area_select** icon  disappears from the Propel Builder Toolbar.




Figure 2.47. Options Dialog

- To move the schematic image within the Schematic view by panning and scrolling.
 - To pan the image: Hold down the Ctrl key and the left mouse button while dragging the image.
 - To scroll vertically: Rotate the mouse wheel. Or, click in the vertical scroll bar.
 - To scroll horizontally: Hold down the Shift key and rotate the mouse wheel. Or, click in the horizontal scroll bar.
- To show the connectivity of a module: right-click the module and choose **Show connectivity**. All nets connected to the module, all pins and ports connected to the nets are highlighted (Figure 2.48).




Figure 2.48. Show Connectivity of the Module

- To highlight an object: select an object and click **Highlight** , or, right-click the object and choose **Highlight** . The object is highlighted in blue (Figure 2.49). Click **Highlight**  again. You can remove highlighting.



Figure 2.49. Highlight an Object

- To change the name of an object:
 - Select the object from the List view of Design View. Information of the selected object is shown in the Properties area (Figure 2.50).




Figure 2.50. Object Properties

- b. Change the name and click **Enter**. The name changes in the Schematic view and List view of Design Info.
- To print a schematic:
 - a. Choose **File > Print Preview**. The Print Preview window (Figure 2.51) opens.




Figure 2.51. Print Preview

- b. Expand the Print Preview window to the desired size.
- c. Click the **Page Setup** button  and adjust the paper size and margins, if necessary.
- d. Click the **Print** button .
- e. Adjust the printer settings, if necessary. Click **Print**.

2.2.9. Connecting Modules

You can connect the pins of modules to other modules or to top-level ports by dragging a line between them or by selecting connection points, or by assigning a constant value to an input pin or bus. Propel Builder does not allow obvious inappropriate connections, such as a connection between two output pins or mismatched buses.

- To connect modules by drawing:
 - Move the cursor to a pin or port. The cursor changes to a pencil icon . Click and hold while dragging to another pin, port, or net. An allowed pin or port shows a green checkmark when you hover over it (Figure 2.52). An allowed net becomes bold when you hover over it (Figure 2.53).




Figure 2.52. Draw a Pin or a Port




Figure 2.53. Draw Nets

- Click on the pin, port, or net that you want to connect to. If the connection is allowed, a line appears connecting the two objects. Propel Builder creates a path around other objects.
- You can connect multiple ports once. When more than one port are selected (Figure 2.54), click **connect**  from the right-click menu to implement it.




Figure 2.54. Select More than One Ports

- d. When the net is complete, right-click to leave the drawing mode.
- To connect modules by selecting points:
 - a. Select the pins, ports, and nets that you want to connect.
 - b. Right-click one of the selected objects. Choose **Connect** .
- To connect pins by auto connecting:
 - a. Right-click a bank and choose **Auto Connect** (Figure 2.55). The Connect Ports dialog appears (Figure 2.56).




Figure 2.55. Action Menu of Right-clicking on Blank

- b. By default, **Auto connect** selects all ports. You can also deselect the interface/clock/rest pins that you do not want to auto-connect ([Figure 2.56](#)).




Figure 2.56. Action Menu of Connecting Ports

Auto connect Rules

Auto connect can initialize three types of connections: Clock/Reset connection, Interface connection, and other connection.

- Clock/Reset Connection

For clock/reset connection, you can choose only one clock port and one reset port in the Driver selection area. In the example below, you can choose only one clock port from osc0_inst.hf_clk_out_o, pll0_inst.clkop_o, or pll0_inst.clkos_o, and one reset port from cpu0_inst.system_reset_n_0 or rstn_i (Figure 2.57).




Figure 2.57. Select One Clock/Reset Port

Following are rules of how clock/reset driver port auto connects to the destination.

- Whether or not the SoC project contains a CPU instance.

If the SoC project contains a CPU instance, and the CPU instance has an output clock/reset port, such as `cpu0_inst.system_resetn_o` (Figure 2.58), the clock/reset of other instances are thus connected to the clock/reset port of the CPU Instance (Figure 2.58).




Figure 2.58. Connecting CPU Instance Reset Output Port

If the SoC project does not contain a CPU instance, clock/reset on all instances connect to the top clock/reset port. Top clock/reset port is the port such as `rstn_j` in Figure 2.58.

The output clock/reset port on one instance should not be connected to its own clock/reset input port, for example, `cpu0_inst.system_resetn_o` should not connect to `cpu0_inst.rst_n_i` in Figure 2.58.

- Interface Connection

Bus interfaces can only connect from one interface to another interface. It is a one-to-one relation, not a one-to-multiple relation, and the interfaces must have the same interface type.

In the example below (see Figure 2.59), `cpu0_inst.AHBL_M1_DATA` is a bus interface, and it can only connect to one destination, `ahbl0_inst.AHBL_S00`. Because they have the same interface type: AHBLite. For interface type, you can check the **Bus Type** in **Design View** (Figure 2.59).




Figure 2.59. Interface Type of `cpu0_inst.AHBL_M1_DATA`

Following rules are how interface connect.

If project contains a CPU instance, the interface connection starts from the CPU instance, then to one bus/bridge instance, and then to another bus/bridge instance one by one (`cpu0 > ahbl0 > ahbl2apb0 > apb0`), finally connects to other instances (`gpio0, uart0`). See Figure 2.60 and Figure 2.61.




Figure 2.60. Interface Connection on from CPU to Bus/Bridge instances in Schematic View

Interface Connection	
cpu0_inst/AHBL_M1_DATA	<input checked="" type="checkbox"/> ahbl0_inst/AHBL_S00
ahbl0_inst/AHBL_M00	<input checked="" type="checkbox"/> ahbl2apb0_inst/AHBL_S0
ahbl2apb0_inst/APB_M0	<input checked="" type="checkbox"/> apb0_inst/APB_S00
ahbl0_inst/AHBL_M01	<input checked="" type="checkbox"/> systemem0_inst/AHBL_S0
apb0_inst/APB_M00	<input checked="" type="checkbox"/> gpio0_inst/APB_S0
apb0_inst/APB_M01	<input checked="" type="checkbox"/> uart0_inst/APB_S0
gpio0_inst/INTR	<input checked="" type="checkbox"/> cpu0_inst/IRQ_S0
uart0_inst/INT_M0	<input checked="" type="checkbox"/> cpu0_inst/IRQ_S1

Figure 2.61. Interface Connection from CPU to Bus/Bridge Instances in Connect Port view

If the last instance connected has the same bus interface type as CPU instance, then it connects back to CPU instance (see Figure 2.62 and Figure 2.63). In Figure 2.64 and Figure 2.65, you can see gpio0_inst.INTR and cpu0_inst.IRQ_S0 have the bus type: Interrupt.




Figure 2.62. Interface connection on other instances connect back to CPU in Schematic View

Interface Connection	
cpu0_inst/AHBL_M1_DATA	<input checked="" type="checkbox"/> ahbl0_inst/AHBL_S00
ahbl0_inst/AHBL_M00	<input checked="" type="checkbox"/> ahbl2apb0_inst/AHBL_S0
ahbl2apb0_inst/APB_M0	<input checked="" type="checkbox"/> apb0_inst/APB_S00
ahbl0_inst/AHBL_M01	<input checked="" type="checkbox"/> systemem0_inst/AHBL_S0
apb0_inst/APB_M00	<input checked="" type="checkbox"/> gpio0_inst/APB_S0
apb0_inst/APB_M01	<input checked="" type="checkbox"/> uart0_inst/APB_S0
gpio0_inst/INTR	<input checked="" type="checkbox"/> cpu0_inst/IRQ_S0
uart0_inst/INT_M0	<input checked="" type="checkbox"/> cpu0_inst/IRQ_S1

Figure 2.63. Interface connection on other instances connect back to CPU in Connect Port view




Figure 2.64. Interface Type of gpio0_inst.INTR




Figure 2.65. Interface Type of cpu0_inst.IRQ_S0

If the project does not contain CPU instance, the interface connection starts from the bus/bridge instance, and then to each bus/bridge instance one by one, and finally connects to the other instances.

Note: If the bus interface is an instruction set, such as CPU0_inst.AHBL_MO_INSTR, it does not perform auto-connect.

- Other connection

If ports have the same port name, for example, rxd_i and uart0_inst.rxd_i, they are connected.

- To assign a constant value to an input pin:
 - a. Select the desired pin and right-click the pin. Choose Assign Constant Value (Figure 2.66).




Figure 2.66. Action Menu of Right-clicking an Input Pin




Figure 2.67. Dialog Box of Assigning Constant Value to an Input Pin

- b. A small dialog box appears (Figure 2.67). Enter the desired value. To erase the value and start over, click X. For all buses (more than one pin), the format is hexadecimal. Make sure the value fits the number of pins in the bus. For example, a 3-pin bus can accept 0-7, but not 8.
- Usually, disconnecting modules just means deleting a net. If the net has multiple branches, just delete one branch, leaving the rest of the nets intact.
 - To disconnect one branch of a net, right-click the pin of that branch and choose  **Disconnect**. The branch going to that pin disappears.
 - To disconnect a whole net, right-click the net and choose **Delete**. The whole net is deleted.

2.2.10. Creating Top-Level Ports

With multiple modules in a Propel Builder project, top-level ports need to be created for a complete Propel Builder module. You can create a top-level port either manually or automatically.

For input ports that connect to more than one pin, such as for clock and reset signals, the manual way is more convenient than the automatic way. If the port names automatically-generated need to be changed, the manual way is better.

For other pins, the automatic way is usually preferred. The automatic way enables you to create the appropriate port type and connect net simultaneously. The automatic way can also create multiple ports at the same time.

The automatic way of creating ports is the most effective. If all the modules are selected, Propel Builder can automatically create ports for all the remaining unconnected pins for selected modules in one step.

- To create a port for a pin or bus manually:
 - a. Right-click in the Schematic view, and choose **Create Port**. The Create Port dialog box pops up (Figure 2.68).




Figure 2.68. Create Port Dialog Box

- b. Enter a name for the port in the **Name** field.
- c. Choose a direction for the port, such as Input in the **Direction** field.
- d. Choose the port type from the **Type** field. The default type is General.
- e. (Optional) Select the **Bus Options**. Enter the number for the most significant bit (MSB) and the least significant bit (LSB). These two options define the bus width.
- f. Click **OK**. The port appears. Figure 2.69 shows an input port, port name of which is on the left. Figure 2.70 shows an output port and an inout port, port names of which are on the right.




Figure 2.69. Input Port




Figure 2.70. Output Port and Inout Port

- g. Connect the port to the module pins. Refer to the [Connecting Modules](#) section for more details.

- To create ports automatically:
 - a. Select the pins that are to be connected to the top-level ports. All the pins in a module can be selected by clicking its block. Any pins that are already connected to a net or a constant value are skipped.
 - b. Right-click on one of the selected pins, interfaces or modules, and choose  **Export**. The selected pins are extended by lines to new top-level port symbols. The names of the ports and nets are added to the List view. Zoom out or scroll the image in the Schematic view to see the new ports.
 - c. Port or net names can be changed, if needed.
- To modify port:
 - a. Click on port, **Properties** window open (Figure 2.71)




Figure 2.71. Properties of Port

- b. Port direction can be modified. You can use the drop-down menu to choose the desired port direction. TCL command is shown in **Design View**. (Figure 2.72).

Note: Port width can only be modified if it is already multi-bit. An error message is prompted out or shown in TCL console, if the input value does not meet rules (Figure 2.72).




Figure 2.72. Port Direction

- c. PortBus MSB, LSB and direction can be modified. Click on PortBus and then use the drop-down menu to choose the desired direction.

Note: An error message is prompted out or shown in TCL console, if the input value does not meet rules (Figure 2.73).




Figure 2.73. PortBus Direction

2.2.11. Adjusting Address Spaces

The Address view shows the base address, size of the address segment, and the end address for each leaf memory-mapped slave connection in the Propel Builder project. Propel Builder can automatically assign address values, while the base address value can be changed manually. The addresses are automatically assigned when master and slave components were connected. The ranges are set when the modules are configured. The end addresses are calculated.

The Lock option on each address space prevents Auto Assign from changing the base address value. The Lock option is selected automatically when you manually change the address value. To reset the address space, clear the Lock option before clicking the Auto Assign icon.

Note: There is no Lock option on LocalMemory. The value of the base address can always be changed, while Auto Assign does not reset it to its original value.

1. In the Propel Builder main window, click the Address tab. The Address view (Figure 2.74) shows.




Figure 2.74. Address View

2. (Optional) Set or clear the Lock options as desired in Address view.
3. (Optional) Double-click the base address in Address view (Figure 2.75). Type the new value and press **Enter**. Values must align with 1K boundaries, such as 0x00000400, 0x00000800, or 0x00000C00. The end address value changes based on the new value. The Lock option is selected automatically at this time.




Figure 2.75. Edit Base Address

Note: If there is a conflict of a related address space, it is shown in red in the graphic.

2.2.12. Validating the Design

The design rule check (DRC) can be run at any time. This checks whether or not there is any illegal connection or overlapping address space.

To perform the design rule check:

1. From the toolbar of the Propel Builder main window, click the **Validate Design** icon . The DRC results appear in the Tcl Console.

2.2.13. Generating the RTL file

The final step for creating a Propel Builder module is to generate a .sbx file, which defines a Propel Builder project, an RTL file, and the instantiation templates. The RTL file includes the Verilog code for the module. The instantiation templates have Verilog and VHDL code to help instantiate the Propel Builder module in a design.

- From the toolbar of the Propel Builder main window, click the **Generate** icon . This step also saves the Propel Builder design and runs the design rules check (DRC).
- From the toolbar of the Propel Builder main window, click the **Generate Memory Report** icon . The SoC design memory information is generated. The memory report folder (mem_report) is generated. All design memory information is shown in detail in the memory report files. The Memory Report files are in HTML format (Figure 2.76).




Figure 2.76. Memory Report

2.2.14. Opening Project in Diamond or Radiant

In a complete SoC project, a Diamond or Radiant project can be created including a Propel Builder design, and after that the SoC project can be opened in Diamond or Radiant software. According to device in the SoC project, Propel Builder can launch Diamond or Radiant software accordingly. If the device is LCMXO3D, MachXO3L, MachXO3LF,

MachXO2, LFMNX, the **Diamond** icon  is shown in the Builder GUI Toolbar. If the device is LIFCL, LFD2NX, LFCPNX,

and LFMXO5, the **Radiant** icon  is shown in the Builder GUI Toolbar. For a template SoC project, you can launch **Diamond** or **Radiant** software directly after template SoC project is created.

- To launch Diamond software:
 - a. Click the **Diamond** icon  from the Propel Builder toolbar.
 - b. Lattice Diamond is launched with a Diamond project generated for SoC at background (Figure 2.77).




Figure 2.77. Diamond Project

- c. (Optional) From the **File List** view of Diamond:
 - modify the top-level RTL file (*<proj_name>_Top.v*) to match the SoC design, presupposition of which is that there is a top-level RTL file in your SoC design.
 - create a top-level RTL file (*<proj_name>_Top.v*) to match the SoC design, if the SoC design is created from an Empty Project template and there is no top-level RTL file in your SoC design.
- d. (Optional) Modify LPF constraint file (*<proj_name>.lpf*) to match the SoC design, if you have modified the SoC design. This step is a must to the SoC design that is created from Empty Project template.
- e. Switch to **Process** view of the Diamond project (Figure 2.78). Make sure at least one programming file (IBIS Model, Verilog Simulation File, VHDL Simulation File, Bitstream File, or JEDEC file) is selected in the **Export Files** section. Available programming files can be different upon specific device included.




Figure 2.78. Generate Programming Files

- f. Right-click **Export Files**, and choose **Run** . The programming file is generated. The programming file can be used in the Diamond Programmer.

Note: Refer to the [Diamond online help](#) for more details of the Diamond project. Re-launch the Diamond project, if the project settings are modified in Propel 2022.1 Builder.

- To launch Radiant software:

- a. Click the **Radiant** icon  from the Propel Builder toolbar.
- b. Lattice Radiant is launched with a Radiant project generated for SoC at background




Figure 2.79. Radiant Project

- c. (Optional) From the **File List** view of Radiant:
 - modify the top-level RTL file (`<proj_name>_Top.v`) to match the SoC design, presupposition of which is that there is a top-level RTL file in your SoC design; or
 - create a top-level RTL file (`<proj_name>_Top.v`) to match the SoC design, if the SoC design is created from an Empty Project template and there is no top-level RTL file in your SoC design.
- d. (Optional) Modify pdc constraint file (`<proj_name>.pdc`) to match the SoC design, if you have modified the SoC design. This step is a must to the SoC design that is created from Empty Project template.
- e. Click  **Run all**. The Programming file is generated. It can be used in the Radiant Programmer.

Notes:

- Refer to the [Radiant online help](#) for more details of the Radiant project.
- About ipx based Radiant implementation flow in Propel Builder:
 - To enable Radiant constraint propagation flow, the design source files need to be switched from original HDL files to ipx file when generating the Radiant project.
 - Ipx based Radiant implementation flow is for project created in later than Propel Builder 2022.1. For project created before Propel Builder 2022.1, use a different method for exporting files. If you want to use ipx flow in these old projects, open them in P2022.1 and regenerate, then export to Radiant to change how it is exported to Radiant. (Figure 2.80).




Figure 2.80. Radiant Project for Project before Propel Builder 2022.1

- Considering certain IP are available at both Propel and Radiant side, only update ip through ipx in Propel Builder side. You must avoid IP update (through ipx) in Radiant side, otherwise, the potential out of sync may cause unexpected issues.

2.2.15. Launching SDK

After a SoC design is completed, Propel SDK can be launched in Propel Builder for software development. For template SoC project, you can launch SDK directly by clicking **Run Propel** icon from Propel Builder toolbar after template SoC project created.

1. Click the **Run Propel** icon  from the Propel Builder GUI Toolbar. Lattice Propel Launcher (Figure 2.81) opens.




Figure 2.81. Lattice Propel Launcher Wizard

- Click **Launch**. Propel SDK GUI opens and the C Project wizard (Figure 2.82) pops up for loading the system and the board support package (BSP) to create a C/C++ project. Enter a project name in the **Project Name** field, such as HelloWorld_C. Click **Next**.




Figure 2.82. Propel SDK GUI and C/C++ Project Wizard

- Click **Next**. The C/C++ project dialog (Figure 2.83) opens.




Figure 2.83. Create C/C++ Project


4. Click **Finish**. The C/C++ project is created and is displayed using the C/C++ perspective. A perspective is a collection of tool views for a particular purpose. The C/C++ perspective is for creating C/C++ programs.

Note: Refer to [Lattice Propel 2022.1 SDK User Guide \(FPGA-UG-02176\)](#) for more details on how to create a C/C++ project and develop the C/C++ project in Propel SDK.

2.3. Verification Project Design Flow

2.3.1. Creating a Verification Project

1. Choose **File** >  **New Design** from the Lattice Propel Builder Menu Bar. The Create System Design wizard opens (Figure 2.84).



Create System Design

Design Information
Enter a name for your design and specify a directory where the design files will be stored.

Project:

Type: SoC Verification

Name: Verification_Project

Location: C:/lsc/workspace **Browse...**

Create Project at C:/lsc/workspace/Verification_Project

< Back Next > Cancel

Figure 2.84. Create System Design – Design Information Wizard

2. Choose SoC Verification from the **Type** field.
3. Enter a project name in the **Name** field, such as Verification_Project.
4. (Optional) Use the “**Browse...**” option to change the project location in the **Location** field, if needed.
5. Click **Next**. The Propel Project Configure wizard is shown as Figure 2.85.




Figure 2.85. Create System Design – Propel Project Configure Wizard

- (Optional) The default Hardware Description Language (HDL) is displayed in the Language area. Use the drop-down menu to change the default language.
- Select an existing SBX design by using **Browse...** to choose an SBX file, such as HelloWorld.
- Click **Next**. The Project Information wizard opens.
- Click **Finish**. A dut_inst of SoC project can be seen in the Schematic view (Figure 2.86).




Figure 2.86. Verification Project

Note: The default instance name of an imported Design Under Test (DUT) is `dut_inst`. By default, its boundary is shown with dotted line, and the filled-in color is gray. If there is any change in the SoC design, the `dut_inst` DUT block can be updated accordingly by double-clicking this `dut_inst` DUT block, or by right-clicking this `dut_inst` DUT block and choosing Reconfig.

- Click the plus sign  of this `dut_inst` DUT block. You can see the whole SoC Design (Figure 2.87). Click the negative sign  to close the expanded bus.




Figure 2.87. Whole SoC Design

2.3.2. Switching SoC Project to Verification Project

Propel Builder supports switching SoC project to verification project manually after creating a SoC project

- Create a SoC Project, such as HelloWorld project. Refer to the [Creating Template SoC Project](#) section for more details.

Note: Corresponding Verification project is created automatically when creating a new empty SOC project. Hello World Templates can have pre-developed Verification projects.

- Click **Switch Verification and Soc Design** icon  from Propel Builder GUI Toolbar. Propel Builder dialog box opens (Figure 2.88), if a project is not saved.




Figure 2.88. Propel Builder Dialog Box

- Click **Yes** in the Propel Builder dialog box. The Propel Builder GUI switches to verify the project (Figure 2.89).




Figure 2.89. Switching to Project Verification

Note: If the SoC project needs to be re-configured, click **Switch Verification and Soc Design**  again to switch the verification project to the SoC project.

2.3.3. Opening a Verification Project

Refer to the [Opening a SoC Existing Project](#) section for procedure in detail.

2.3.4. Adding Modules, IP and VIPs

Refer to the [Adding Modules](#) section for procedure in detail.

2.3.5. Working with the Schematic View

Refer to the previous [Working with the Schematic View](#) section for procedure in detail.

2.3.6. Connecting Modules

Refer to the previous [Connecting Modules](#) section for procedure in detail.

2.3.7. Monitoring DUT

This feature is available to a SOC Verification project only. In Propel Builder, the pin inside DUT can be connected to the input pin of a VIP. The connected pins can be found at both ends of the orange line, as shown in [Figure 2.90](#). Only pin and pin bus are supported in the current release of Propel Builder.




Figure 2.90. Monitoring DUT

The testbench generated for this Verification project is shown in [Figure 2.91](#). This testbench file can be used for simulation.

```

75     logic sysclk_rst_gen1_inst_dut_clk_i_net;
76
77     /*-----Connection Block-----*/
78     /* This section cover all the connections that related to internal*/
79     /* signals of DUT, or interface(e.g, AHBL Master BFM).....*/
80     /*-----*/
81
82     assign sysclk_rst_gen1_inst_dut_clk_i_net = dut_inst.osc0_inst.hf_clk_out_o;
83
84     /*-----BFM Block-----*/
85     /* This section is reserved for user to create stimulus using BFM.*/
86     /* APIs.....*/
87     /*-----*/
88
89     ....
90
91     sysclk_rst_gen1
92     sysclk_rst_gen1_inst
93     (
94         .dut_clk_i(sysclk_rst_gen1_inst_dut_clk_i_net),
95         .dut_clk_o(sysclk_rst_gen1_inst_dut_clk_o_net),
96         .tb_rst_o(sysclk_rst_gen1_inst_tb_rst_o_net)
97     );

```

Figure 2.91. Testbench of the Verification Project

2.3.8. Generating Simulation Environment

1. Click the **Generate** icon  from the Propel Builder Toolbar to generate a testbench file including the scripts for the chosen simulator, file list for HDLs, and some other files. The testbench file structure is shown in [Figure 2.92](#).

```

[sim]                                -- generated simulation environment
    [hdl_header]
soc_regs.v                            -- register definitions of all the components in DUT/SOC
sys_platform.v                        -- base address, user settings of all the components in DUT/SOC
    [misc]
*. *                                  -- all the mem, hex, txt files will be copied here
    flist.f                            -- file list for HDLs
    msim.do                            -- do script for simulator, it can be qsim for Questasim
    wave.do                            -- do script for adding signals in waveform window
    <project_name>.sv                 -- top testbench, SystemVerilog based
    
```

Figure 2.92. Testbench File Structure

Unlike those HDLs generated in the SOC design, the testbench generation in the Verification project is just a start point for you to work with. Make sure that you generate a new testbench, if there is an existing simulation environment. A dialog box pops up prompting you to make a choice of Yes or No ([Figure 2.93](#)).




Figure 2.93. Propel Builder – A Reminding Dialog Box

2.3.9. Launching Simulation

1. Click **Launch Simulation** icon  from the Propel Builder Toolbar to launch simulation.
2. The default simulation tool, ModelSim, OEM version, opens ([Figure 2.94](#)).




Figure 2.94. Simulation GUI

Note: Before launching simulation, you can change Simulator to Questasim by clicking **Design > Options** from the Builder Menu bar. Builder Options Wizard opens (Figure 2.95). Click **Directories** to set a desired Questasim Location.




Figure 2.95. Builder Options Wizard

2.4. Advanced Usage

2.4.1. Supported Interface

Lattice Propel Builder and IP Packager share the same usage of interfaces. These interfaces are listed below.

- Interrupt
- AMBA3 AHB Lite
- AMBA3 APB
- AMBA4 AXI4
- AMBA4 AXI4 Lite
- AMBA4 AXI4 Stream
- Localbus

Refer to the [IP Packager](#) section for detailed usage of these interfaces in the IP Packager.

2.4.2. Supported Language

Propel 2022.1 Builder supports the following languages:

- Verilog HDL
- SystemVerilog
- VHDL
- Mixed Verilog/VHDL

Currently, verification projects only support Verilog HDL.

2.4.3. Supported Hierarchical IP

Hierarchical IP instantiates a hierarchical component that contains a reference to a design along with a description of the top-level interface of the component.

Click **Expand IP** sign  on the left corner of the hierarchical IP ([Figure 2.96](#)) to show the detailed design scope of this IP ([Figure 2.97](#)).




Figure 2.96. Hierarchical IP




Figure 2.97. Hierarchical IP Scope in Detail

2.4.4. Export Interface

AHB Lite or APB interface ports can be connected to external IP outside of Propel Builder. You must use AHB-Lite or APB feedthrough modules to hold the address space (when feedthrough module is configured as master) or memory map (when feedthrough module is configured as slave) information. The interface to be exported should be connected first to feedthrough, then the other end of the feedthrough can be exported. An example is shown in Figure 2.98.




Figure 2.98. Export Interface Example

In the example above, to export interface `ahbl_int_inst.AHBL_M02`:

1. Instantiate an AHB-Lite feedthrough module from IP catalog, and configure it as slave. The instance name here is `ahbl_s0_inst`.
2. Set the address width and data width for the memory map.
3. Connect `ahbl_int_inst.AHBL_M02` to `ahbl_s0_inst.AHBL_S0`.
4. Export `ahbl_s0_inst.AHBL_M0` for external IP.

You can see the memory map for `ahbl_s0_inst` is shown in the Address Editor (Figure 2.99).

Schematic	Address	Start Page			
Cell		Base Address	Range	End Address	Lock
▼ apb_m0_inst					
▼ apb_m0_inst/APB_M0(32 address bits: 64K)					
	apb_s0_inst/APB_S0	0x00010800	1K	0x00010BFF	<input checked="" type="checkbox"/>
	apb_s1_inst/APB_S0	0x00010C00	1K	0x00010FFF	<input checked="" type="checkbox"/>
	apb_s2_inst/APB_S0	0x00011000	2K	0x000117FF	<input checked="" type="checkbox"/>
▼ cpu_0_inst					
▼ LocalMemory					
	cpu_0_inst/pic_timer_registers	0xFFFF0000	2K	0xFFFF07FF	
▼ cpu_0_inst/AHBL_M0_INSTR(32 address bits: 4G)					
	sys_mem_0_inst/AHBL_S0	0x00000000	64K	0x0000FFFF	<input checked="" type="checkbox"/>
▼ cpu_0_inst/AHBL_M1_DATA(32 address bits: 4G)					
	ahbl_s0_inst/AHBL_S0	0x00010000	2K	0x000107FF	<input checked="" type="checkbox"/>
	apb_s0_inst/APB_S0	0x00010800	1K	0x00010BFF	<input checked="" type="checkbox"/>
	apb_s1_inst/APB_S0	0x00010C00	1K	0x00010FFF	<input checked="" type="checkbox"/>
	apb_s2_inst/APB_S0	0x00011000	2K	0x000117FF	<input checked="" type="checkbox"/>
	sys_mem_0_inst/AHBL_S1	0x00000000	64K	0x0000FFFF	<input checked="" type="checkbox"/>

Figure 2.99. Memory Map for ahbl_s0_inst in Address Editor

2.4.5. Define Custom Template

Saving design as template is an enhancement feature of Propel Builder, which allows you to create your own new project template based on existing design. You can deploy this template into Propel Builder later or share it with others by saving template into a .ptmp file. See below on how to make a .ptmp file)

This function takes effect from Propel Builder 2022.1, so the design created in earlier Propel Builder versions cannot define its custom template.

- Export current template configuration:

Choose **Tools > Create Template** from Propel Builder Menu Bar. Template Configuration (Figure 2.100) opens.




Figure 2.100. Export Template Configuration Page

- a. Fill in general information such as Template name, Description, Vendor.
- b. Select Processor, Device Family, and Supported Boards:
 - The device used in the current design is listed by default. You must make sure the design can work on all the devices in the list.
 - How:
 - Click on IP instance in **Schematic view**, the **Design View** shows the corresponding information of this IP. Check VLNV for this IP name (Figure 2.101). Go to **IP Catalog**, click on  before this IP to show the **IP Information**. In **Device Supported** area, all the devices this IP supports are listed (Figure 2.102). Make

sure all the IP instances in the design have the device support which are listed in the Board Family list in Template Configuration (Figure 2.100).




Figure 2.101. Check IP Name in Design View




Figure 2.102. Check Device Supported in IP Information

- You can add the board information manually in **Supported Boards** (refer to Figure 2.4 for board information) and you must ensure the correctness of the board information and the design can work on this board.
- c. Template Resources:
 - Optional resources include the newly created project such as C application project, user RTLs.

d. Output:

- By default, after you click the **Generate** button, the new template can be installed to your custom template folder, which is a folder named **PropelTemplateLocal** under \$HOME (Figure 2.103).




Figure 2.103. Export Template to PropelTemplateLocal Folder

- If you want to share this template, you can click **Share Template** and output this template to a .ptmp file which can be later installed to Propel Builder by other people.
- Template manager page for custom templates:

You can import/delete/export a selected template in **Template Manager** when creating a new system design (Figure 2.104 and Figure 2.105).




Figure 2.104. Template Manager Entry




Figure 2.105. Templates Manager Page

- To import a template, click **Import** (Figure 2.105), and then choose the desired .ptmp file (Figure 2.106).




Figure 2.106. Import ptmp File

- Custom template installation path:
Custom templates are installed in \$HOME/PropelTemplateLocal directory by default (Figure 2.107).




Figure 2.107. Template Manager Page

You can move it to another location in **Options** page ([Figure 2.108](#)).




Figure 2.108. Template Manager Page – Change to New Location

2.4.6. Include Sub Sbx File

Right Click on **Schematic View** and choose **Add Sbx Instance** (Figure 2.109), and then chose the sbx file you want to input (Figure 2.110).




Figure 2.109. Right Click on Schematic View




Figure 2.110. Input sbx File and Instance Name

3. IP Packager

IP Packager is a tool for you to create an IP package easily. You can edit port, file, parameter, and memory in the IP Packager, and pack a customized IP directly.

IP Package is a collection of all required files related to an IP. All the related files are organized in different directories (Figure 3.1).

```

- [IP Package]
  - metadata.xml
  - [rtl]
  - [testbench]
  - [ldc]
    - constraint.ldc
  - [driver]
    - [ip_eval]
  - [plugin]
    - plugin.py
  - [doc]
    - introduction.html
    - EULA.txt
    
```

Figure 3.1. Example Directories and Files of an IP Package

- metadata.xml [mandatory]: XML metadata file which mainly describes legal usage and interface of an IP.
- rtl [mandatory]: Directory for parameterized HDL source files. HDL source files contain configurable parameters for you to configure.
- testbench [optional]: Directory for test bench files.
- ldc [optional]: Directory template constraint file. The file name should be constraint.ldc.
- driver [optional]: Directory for driver source code files.
- plugin [optional]: Directory for Python script to implement internal logic of the soft IP. The file name of Python script should be plugin.py.
- doc[mandatory]: Directory for documentation files. It should contain one mandatory introduction file, one mandatory license agreement file, and other optional documents.

The custom IP package can be used in Propel Builder for SoC design. IP instance package (Figure 3.2) is generated when user configures IP in Propel Builder.

```

- <instance_name>
  - <instance_name>.cfg
  - <instance_name>.ipx
  - component.xml
  - design.xml
  - [rtl]
    - <instance_name>.v
    - <instance_name>_bb.v
  - [constraints]
    - <instance_name>.ldc
  - [driver]
  - [ip_eval]
  - [misc]
    - <instance_name>_tpl.v
    - <instance_name>_tpl.vhd
    
```

Figure 3.2. Example Directories and Files of an IP Instance Package

3.1. Launching IP Packager

1. Choose **Tools** >  **IP Packager** from the Lattice Propel Builder Menu Bar.

Note: You can also launch IP Packager from Radiant 3.2 or later version if you have already installed Radiant. To launch IP Packager, you can go to the Windows Start menu and choose **Programs > Lattice Radiant Software > Accessories > IP Packager**.

2. IP Packager is launched ([Figure 3.3](#)).




Figure 3.3. IP Packager GUI

3.2. Packing Custom IP Flow

3.2.1. Opening an IP Directory

1. Choose **File** >  **Open IP Directory** from the Propel Builder Menu or Click the **Open Design** icon  from Propel Builder Toolbar. The Select Folder dialog opens ([Figure 3.4](#)).




Figure 3.4. Select Folder Dialog

2. Choose a desired IP directory.
3. Click **Select Folder**. The IP Packager GUI shows the IP Package project (Figure 3.5). IP package project includes three mandatory parts (Meta Data, Design File, and Doc) and two optional parts (Test Bench and Misc) that need to be edited. Refer to the [Editing IP](#) section for more details.




Figure 3.5. IP Packager with IP Project Details

Note: If you prepared all directories and files of an IP module in advance, the IP Packager can load the information. If you do not want to update the IP module information, you can skip the [Editing IP](#) section below.

3.2.2. Editing IP

- From the IP Packager Project area, click **Meta Data**. The IP Packager GUI shows Meta Data information in detail (Figure 3.6).




Figure 3.6. IP Packager with Meta Data Details

- To configure basic information:
 - Click **Basic Info** from Meta Data view (Figure 3.7).




Figure 3.7. Meta Data View

- You can see the Basic Info properties in detail as shown in Figure 3.8.




Figure 3.8. Configure Basic Info

- Configure the basic information by entering desired value for a property or checking the checkbox for the property in the property field. For example, click the **Vendor** field to enter a desired vendor value.
Note: IP Packager supports both Radiant and Propel software. IP Packager currently is based on Radiant 2022.1 but does not support Radiant version of which is lower than 2022.1. “Minimal Radiant version” should be set to 2022.1 or 2022.1 +. For Propel, IP Packager currently is based on Propel 2022.1, not support Propel version of which is lower than 2022.1. “Minimal Propel version” should be set to 2022.1 or 2022.1+. If the version of Radiant or Propel is invalid, a warning message is shown (Figure 3.9).




Figure 3.9. Warning Message of the Invalid Radiant and Propel Version

b. To configure parameters:

- Parameters are settings that can be used in Ports/Interfaces/Memory map configuration. You can think of them as macros. For example, click on Port *gpio_i*, you can see its configuration. In *gpio_i*, there is a value using *EXTERNAL_BUF* that is defined in Parameters (Figure 3.10).




Figure 3.10. Preview on Parameters

- Two-level hierarchy (Tab/Group) is used to categorize the parameters. Click on the **IP Preview** icon from the toolbar (Figure 3.11), you can see the hierarchy relations (Figure 3.12).




Figure 3.11. Two-Level Hierarchy to Categorize Parameters




Figure 3.12. IP Preview Showing Two-level Hierarchy in Parameters

- Naming rules for parameters:
 - Parameters in all groups should not have the same name, which is similar that macro redefinition is not allowed.
 - Characters support in naming are letters with mixed case, numbers and underscore (_).
- To add a parameter, right-click Parameters from Meta Data view and choose **Add Parameter Tab** (Figure 3.13). **Tab1** is created under **Parameters**.




Figure 3.13. Right-click Menu of Parameters in the Meta Data View

- Right-click **Tab1** under **Parameters** from Meta Data view, and choose **Add Parameter Group**. **Group1** is newly added under **Tab1** (Figure 3.14).




Figure 3.14. Group1 Added to Tab1

- Right-click **Group1** under **Tab1** from the Meta Data view, and choose **Add Parameter**. **NewParam1** is newly added under **Group1** (Figure 3.15).

Meta Data		
Basic Info		
Parameters		
Property	Value	Note: Click table to change value.
title		
type	param	
value_type	string	
default		
value_expr		
options		
output_formatter		
bool_value_mapping		
editable		
hidden		
drc		
regex		
value_range		
config_groups		
description		

Figure 3.15. NewParam1 Added to Group1

- Double-click **NewParam1** to rename the parameter (Figure 3.16). The parameter name is also used as the unique ID of the parameter setting.




Figure 3.16. Rename a Parameter

- Double-click the property value field to enter the desired parameter value, or select the desired value from drop-down menu (Figure 3.17). The properties are thus configured. Property listed in bold must be configured. The details of each property is shown in Table 3.1.




Figure 3.17. Configure a Parameter

Table 3.1. Details of Parameter Property

Property	Value	Mandatory	Description
title	String	No	Short title of the setting. If “title” is not specified, value of “setting” is used. Example: title=“Device Architecture”
type	param, input, command	Yes	A setting can be a Verilog parameter, Verilog macro definition or user input. Param, 94olean_macro and input settings can be used to compute values of other param and input settings. They only differ in generated files. Param is written out as a Verilog parameter value of the IP module. 95oolean_macro is translated to a Verilog macro definition by the <i>define compiler</i> directives, but input is not. Command shows as a button. Example: type=“param”
value_type	bool, string, int, float, path	Yes	Type of the value. Supported types are bool, int, float, string, and path. The int type supports unlimited precision. The float type supports the precision of float type of C programming language. Refer to the Characteristics of Floating Types section of the 1999 ISO/IEC C Standard for details. The path type indicates a string which represents a path. “/” is used as separator. Example: value_type=“string”
default	Python expression	No	Default value of the setting. If the setting has no “default” attribute but has “options” attribute, the first option is picked as default value. If the setting has neither “default” attribute nor “options” attribute, the initial value of setting is set to 0 for int, 0.0 for float, “” for string and False for bool. By default, it is not allowed to reference to other setting values. Use value_expr as reference values. Example: default=“LIFCL”
value_expr	Python expression	No	Python expression to compute the value of the setting. The result is used as the parameter value if the setting is not editable. For example, divider is calculated by frequencies.

Property	Value	Mandatory	Description
			Example: value_expr="int(round((sys_clock_freq * 250.0) / i2c_left_desired_frequency))-1"
options	Python list or list of tuples	No	Candidate options for the setting, which is used by GUI to display a dropdown selector. It can be set to a simple list or a list of tuples. If it is a simple list, elements are displayed and written. If it is a list of tuples, the first item in tuple is displayed and the second item in tuple is written. Example: options="[0.1, 0.2, 0.5, 1.0]"
output_formatter	str	No	Control how parameter values are written in output RTL files. Following formatters are supported. Str: parameter values are written as strings nostr: quotation marks of strings are removed Example: output_formatter="str"
bool_value_mapping	Python tuple or list with 2 string elements	No	The map-to-map bool values to dedicated strings. By default, bool values are written as 1, 0. Example: bool_value_mapping="(True, 'False')"
editable	Python expression	No	Python expression to determine if the setting is editable. When a setting is not editable, it is grayed out in GUI display and its value is computed by value_expr. Otherwise, user input is used. Example: editable="(FEEDBACK_PATH == 'PHASE_AND_DELAY') (FEEDBACK_PATH is a setting ID in metadata.xml)
hidden	True	No	Python expression to determine whether or not the setting is hidden in GUI. If hidden is set to True (default is False), the item is hidden in GUI. The expression is resolved to 96boolean value after the user setting is changed. Example: hidden="True"
drc	Python expression	No	Python expression to do DRC on the setting. True means DRC pass. Example: drc="check_valid_addr_pre(I2C_LEFT_ADDRESSING_PRE,i2c_left_addressing_width)" (check_valid_addr_pre is defined in plugin.py setting ID: I2C_LEFT_ADDRESSING_PRE i2c_left_addressing_width)
regex	Regular expression	No	Regular expression to do DRC on the value. For example, the value should be prefixed by "0b". Example: regex="0b[01]+"
value_range	Python tuple or list with 2 comparable elements	No	Valid range of setting value, which is used to do DRC on the setting. The maximum value can be infinity "float('inf')". Example: value_range="(0, 1023) if(i2c_right_enable) else (-9999, 9999)"
config_groups	Python expression	No	A name or names to group settings together. It is copied from IP-XACT configGroups attribute, and only supports "SystemBuilder" value. If it is defined, related RTL parameter is brought out to IP instance top module, so that System Builder can re-define its value.
Description	String	No	Detailed description of the setting.
Macro_name	id, value	No	Specify how to name the Verilog macro in 'verilog_macro' type setting item, the ID or value of this setting item. The default value is 'setting', which means the setting's ID will be defined as a Verilog macro. If it is set as 'value', the evaluated

Property	Value	Mandatory	Description
			setting value is the Verilog macro. Example: maro_name= "value" Result: `define <setting value> Note: This is only be considered in the setting item whose 'value_type' attribute is set to 'string'.

- Repeat steps above to configure all parameters as desired.
- c. To configure Ports:
- Click **Ports** from the Meta Data Tree, three port types (IN, OUT, INOUT) (Figure 3.18) are listed.




Figure 3.18. Three Port Types

- Right-click **IN** from the Ports area, and choose **Add Port** (Figure 3.19).




Figure 3.19. Right-click Menu of the IN Port

Note: You can add all ports by using **Infer Ports from HDL**, if you prepare valid RTL files and add RTL files in Design Files section. Click **Infer Ports from HDL**, the Add inferred ports to meta data wizard pops up (Figure 3.20). If you have added some ports and then choose **Infer Ports from HDL**, all the previously-added ports are removed and only ports from the HDL file can be added.




Figure 3.20. Add inferred ports to meta data Wizard

- **NewPort1** is created. Double click NewPort1 to rename the port (Figure 3.21).




Figure 3.21. Rename an IN Port

- Configure all properties of the IN port as desired (Figure 3.22). Property listed in bold must be configured. The details of each property is shown in Table 3.2.




Figure 3.22. Configure an IN Port

Table 3.2. Details of Port Property

Property	Value	Mandatory	Description
range	Python tuple or list with two-integer elements	No	Range of this port. It should be a Python expression whose evaluation result is a tuple or array with two elements. Example: range="(A_WDT-1, 0)" (A_WDT is a setting ID)
conn_port	Valid Verilog module name	No	Name of port of IP core module to which this port connects. Value of "name" is used if "conn_port" is not specified. Example: conn_port="Clk"
conn_range	Python tuple or list with two-integer elements	No	Range of conn_port. It should be a Python expression whose evaluation result is a tuple or array with two elements. Example: conn_range="(A_WDT-1, 0)" (A_WDT is a setting ID)
stick_high	Python expression	No	Python script. True: tie this port to 1. Example: stick_high="True"
stick_low	Python expression	No	Python script. True: tie this port to 0. Example: stick_low="no_seq_pins()" (no_seq_pins is defined in plugin.py)
stick_value	Python expression	No	Python script. Tie port to the evaluation result of this attribute.
Dangling	Python expression	No	Python script. True: keep this port unconnected. Example: dangling="not USE_COUT" (USE_COUT is a setting ID)
attribute	Python expression	No	Python script. The value can be written to the .v file as the attribute of the port. Example:

Property	Value	Mandatory	Description
			attribute="" (* AAA, BBB=1 *)" => (* AAA, BBB=1*) input PORT;
port_type	String	No	'data', 'reset' and 'clock' are valid values. The default value is 'data'. Port_type can be passed to the IPXact component.xml as a lscqip:isClk or lsscqip:isRst node in venderExtensions in component/model/ports/port.

- Repeat steps above to configure all ports as desired.
- d. To configure Interfaces:
- Right-click **Interfaces** from the Meta Data view, and choose **Add Interface** (Figure 3.23). A new interface **NewInterface1** is created.




Figure 3.23. Right-click Menu of an Interface

- Double click **NewInterface1** to rename interface (Figure 3.24).




Figure 3.24. Rename Interface

- Configure the interface as desired (Figure 3.25).




Figure 3.25. Configure an Interface

- Repeat steps above to configure all interfaces as desired.

- e. To configure Memory Map:
- Right-click **Memory Map** from the Meta Data Tree, and choose **Import Memory Map from CSV** (Figure 3.26). New memory map is created (Figure 3.27).
 - **Note:** Propel 2022.1 Builder only supports using **Import Memory Map from CSV** to create memory map. There are some issues if you use **Add Memory Map**.




Figure 3.26. Right-click Menu of a Memory Map




Figure 3.27. Generate New Memory Map

- From the IP Packager Project area, click **Design Files**. IP Packager GUI shows the Design Files information (Figure 3.28).




Figure 3.28. IP Packager with Design File Details

- Click the **Add** button to select a desired rtl file in the Design Files field. Click the **Remove** button to remove an RTL file. Use the “...” option to add a desired timing constraint file and synplify Pro Constraint file.

Note: Design file configuration is mandatory. Specify at least one RTL file. If the RTL file needs to be encrypted, check the **Encryption** option for it.

3. From the IP Packager Project area, click **Test Bench**. The Test Bench information is shown in detail (Figure 3.29).




Figure 3.29. IP Packager with Test Bench Details

Follow the steps as those for configuring the Design Files to configure the Test Bench. The Test Bench files configuration is not mandatory.

- From the IP Packager Project area, click **Misc**. The Misc related information is shown in detail (Figure 3.30). Configure Misc information as desired.




Figure 3.30. IP Packager with Misc Details

- From the IP Packager Project area, click **Doc Assistant**. The Doc Assistant information is shown in detail (Figure 3.31).




Figure 3.31. IP Packager with Doc Assistant Details

- Enter the desired title, description, and device in the **Title**, **Description**, and **Device support** fields accordingly.
- Double-click and enter a revision in **Revision** field. Double-click and enter revision contents in **Content** field. Refer to Figure 3.32 as an example. Click the **Add** button. A new blank row is added to the Revision History area. You can add desired revision and contents accordingly. Select the revision you want to delete, and click the **Remove** button to remove a Revision.
- Click the **Save and Add to IP Package** button to create an introduction html page and save this file to the IP package.




Figure 3.32. Configure Doc Assistant

3.2.3. Previewing IP

1. Choose **Edit** >  **IP Preview** from Propel Builder menu. Or, click the **IP Preview** icon  from Propel Builder Toolbar.
2. IP Preview pops up showing the configuration component for the IP module (Figure 3.33), if the IP project configuration is correct. Otherwise, the IP Packager pops up an error message (Figure 3.34).




Figure 3.33. IP Preview Shows Configuration for IP Module



Figure 3.34. IP Packager Pops up Error Message

3.2.4. Packaging IP

1. Choose **Edit** >  **Package IP** from Propel Builder menu. Or, click the **Package IP** icon  from Propel Builder Toolbar.
2. IP Packager pops up a message showing the packaging is completed successfully (Figure 3.35).




Figure 3.35. IP Packager Pops up Successful Packaging Message

Note: When the setting value is changed, the packaging operation is disabled. You must perform a preview operation before packaging. If the preview is successful, the packet operation is enabled. Otherwise, error messages are displayed in the output widget.

3.3. Editing IP Package Files

3.3.1. Metadata File

Metadata.xml can be generated after editing IP. You also can manually edit the file. IP Platform uses XML file to describe metadata of a soft IP. Namespace “lscip” is used in XML file. The content of the XML file consists of three mandatory nodes including <general>, <settings> and <ports>, five optional nodes including <busInterfaces>, <addressSpaces>, <memoryMaps>, <componentGenerators> and <estimatedResources>. One optional new child node <outFileConfigs> is added to support the customized IP generation flow in Propel (Figure 3.36).

```

<lscip:ip
xmlns:lscip="http://www.latticesemi.com/XMLSchema/Radiant/ip"
xmlns:xsi="http://www.w3.org/2001/XMLSchema-instance"
version="1.0">
  <lscip:general>
    .....
  </lscip:general>
  <lscip:settings>
    .....
  </lscip:settings>
  <lscip:ports>
    .....
  </lscip:ports>
</lscip:ip>

```

Figure 3.36. Example XML of Metadata Layout

1. <general> node: describes general information about a soft IP, for example, name, version, and category. Table 3.3 shows the child nodes of <general> node.

Table 3.3. Child Nodes of General Node

Child Node	Mandatory	Description
vendor	Yes	Soft IP vendor. Official soft IP should have vendor name. Example: "latticesemi.com"
library	Yes	Library of the soft IP. If "library" is not set, the default value "ip" is used. Example: "ip", "interface"
name	Yes	Name of the soft IP. The name must be unique among soft IP of the same vendor and library. Example: "adder"
display_name	No	Name to be displayed in the software. If "display_name" is not set, software displays "name" directly. Example: "Adder"
version	Yes	Version of the soft IP. Example: 1.0.0
category	Yes	Category of the soft IP. Category can be hierarchical. Levels are separated by ",". Example: Memory_Modules,Distributed_RAM
keywords	No	Keywords of the soft IP. Multiple keywords are separated by ",". Example: BusType_AHB,BusType_APB
min_radiant_version	Yes	The minimal Radiant version, which supports the soft IP. Example: 1.0 (no service pack), 1.0.1 (with service pack)
max_radiant_version	No	The maximal Radiant version, which supports the soft IP. Example: 2.0.
supported_products	No	FPGA products supported by the soft IP.
Type	No	Enhancement for cpu IP.
Min_esi_version	No	The minimal ESI version, which supports the soft IP. Enhancement for esi.
Max_esi_version	No	The maximal ESI version, which supports the soft IP. Enhancement for esi.
Supported_platforms	No	Default is Radiant, specific for esi.

2. <settings> node: describes parameters information that should contain one or more <setting> nodes. In an IP instance package, Verilog parameters are used to configure the soft IP. All user configurable parameters should be added to the <settings> section as <setting> nodes. Beside parameters, you can add <setting> nodes for user-input only. Table 3.4 shows attributes of <setting> nodes.

Table 3.4. Attributes of Setting Nodes

Attribute	Value	Mandatory	Description
id	String	Yes	The unique ID of the setting, which is also be referred as: Parameter name in RTL codes Python variable name Tcl variable name To make value of the “id” valid in Verilog HDL, Python and Tcl, it should consist of only letters, digits, and underscore. The first character should be letter. Example: id=“num_outputs”
title	String	No	Short title of the setting. If “title” is not specified, value of “setting” is used. Example: title=“Number of Output”
type	param, input, command	Yes	A setting can be a Verilog parameter, Verilog macro definition or user input. Param, 112oolean_macro and input settings can be used to compute values of other param and input settings. They only differ in generated files. Param is written out as a Verilog parameter value pf the IP module, 112oolean_macro is translated to a Verilog macro definition by the define compiler directives, but input is not. Command shows as a button. Example: type=“param”
value_type	bool, string, int, float, path	Yes	Type of the value. Supported types are bool, int, float, string, and path. The int type supports unlimited precision. The float type supports the precision of float type of C programming language. Refer to the Characteristics of Floating Types section of the 1999 ISO/IEC C Standard for details. The path type indicates a string which represents a path. “/” is used as separator. Example: value_type=“int”
default	Python expression	No	Default value of the setting. If the setting has no “default” attribute but has “options” attribute, the first option is picked as default value. If the setting has neither “default” attribute nor “options” attribute, the initial value of setting is set to 0 for int, 0.0 for float, “” for string and False for bool. Example: default=“1.0”
value_expr	Python expression	No	Python expression to compute the value of the setting. The result is used as parameter value if the setting is not editable. For example, divider is calculated by frequencies. Example: value_expr=“ int(round((sys_clock_freq * 250.0) / i2c_left_desired_frequency))-1”
options	Python list or list of tuples	No	Candidate options for the setting, which is used by GUI to display a dropdown selector. It can be set to a simple list or a list of tuples. If it is a simple list, elements are displayed and written. If it is a list of tuples, the first item in tuple is displayed and the second item in tuple is written. Example: options=“[0.1, 0.2, 0.5, 1.0]”

Attribute	Value	Mandatory	Description
output_formatter	str	No	Control how parameter values are written in output RTL files. Following formatters are supported. Str: parameter values are written as strings nostr: quotation marks of strings are removed Example: output_formatter="str"
bool_value_mapping	Python tuple or list with 2 string elements	No	The map-to-map bool values to dedicated strings. By default, bool values are written as 1, 0. Example: bool_value_mapping=("True', 'False')
editable	Python expression	No	Python expression to determine if the setting is editable. When a setting is not editable, it is grayed out in GUI display and its value is computed by value_expr. Otherwise, user input is used. Example: editable="(FEEDBACK_PATH == 'PHASE_AND_DELAY') (FEEDBACK_PATH is a setting ID in metadata.xml)
hidden	True	No	Python expression to determine whether the setting is hidden in GUI. If hidden is set to True (default is False), the item is hidden in GUI. The expression is resolved to 113oolean value after the user setting is changed. Example: hidden="True"
drc	Python expression	No	Python expression to do DRC on the setting. True means DRC pass. Example: drc="check_valid_addr_pre(I2C_LEFT_ADDRESSING_PRE,i2c_left_addressing_width)" (check_valid_addr_pre is defined in plugin.py setting ID: I2C_LEFT_ADDRESSING_PRE i2c_left_addressing_width)
regex	Regular expression	No	Regular expression to do DRC on the value. For example, the value should be prefixed by "0b". Example: regex="0b[01]+"
value_range	Python tuple or list with 2 comparable elements	No	Valid range of setting value, which is used to do DRC on the setting. The maximum value can be infinity "float('inf')". Example: value_range="(0, 1023) if(i2c_right_enable) else (-9999, 9999)"
config_groups	Python expression	No	A name or names to group settings together. It is copied from IP-XACT configGroups attribute, and only supports "SystemBuilder" value. If it is defined, related RTL parameter is brought out to IP instance top module, so that System Builder can re-define its value.
Description	String	No	Detailed description of the setting.
Group1	String	No	Group the settings. Settings of the same "group1" is displayed as sub-items under a group item on GUI. The settings with the same "group1" should be written continuously if you want GUI to group them under one group item. Otherwise, you can see multiple groups with the same name in GUI. Example: group1= "Output Setting"
group2	String	No	Group the "group1" groups. "group1" groups of the same "group2" is displayed in a separate page on GUI. So, two-level hierarchy is supported in GUI display. Unlike 'group1', you need not write setting nodes with the same 'group2' continuously. You must follow the rule for 'group1' that all the settings with the same 'group1' must be in the same 'group2'.

Attribute	Value	Mandatory	Description
Macro_name	id, value	No	Specify how to name the Verilog macro in 'verilog_macro' type setting item, the ID or value of this setting item. The default value is 'setting', which means the setting ID is defined as a Verilog macro. If it is set as 'value', the evaluated setting value is the Verilog macro. Example: maro_name= "value" Result: `define <setting value> Note: This is only be considered in the setting item whose 'value_type' attribute is set to 'string'.

3. <ports> node: IP module package has some ports in its implementation. These ports should be described in <ports> section as <port> child nodes. If an input port is stuck to fixed value, or an output port is dangling, the port is not used and is invisible after generation. Table 3.5 shows the attributes of <port> nodes.

Table 3.5. Attributes of Port Nodes

Attribute	Value	Mandatory	Description
name	Valid Verilog port name	Yes	Name of a port. Example: name="Clk"
dir	in, out, inout	Yes	Direction of a port. Example: dir="in"
range	Python tuple or list with 2 int elements	No	Range of this port. It should be a Python expression whose evaluation result is a tuple or array with 2 elements. Example: range="(A_WDT-1, 0)" (A_WDT is a setting ID)
conn_mod	Valid Verilog module name	Yes	Name of an IP core module to which this port connects. Example: conn_mod="counter"
conn_port	Valid Verilog module name	No	Name of port of an IP core module to which this port connects. Value of "name" is used, if "conn_port" is not specified. Example: conn_port="Clk"
conn_range	Python tuple or list with 2 int elements	No	Range of conn_port. It should be a Python expression whose evaluation result is a tuple or array with 2 elements. Example: conn_range="(A_WDT-1, 0)" (A_WDT is a setting ID)
stick_high	Python expression	No	Python script. True: tie this port to 1. Example: stick_high="True"
stick_low	Python expression	No	Python script. True: tie this port to 0. Example: stick_low="no_seq_pins()" (no_seq_pins is defined in plugin.py)
stick_value	Python expression	No	Python script. Tie port to the evaluation result of this attribute.
Dangling	Python expression	No	Python script. True: keep this port unconnected. Example: dangling="not USE_COUT" (USE_COUT is a setting ID)
bus_interface	Valid bus interface name	No	Bus interface name defined in <busInterfaces> node. Example:

Attribute	Value	Mandatory	Description
			bus_interface=" ahb_slave_0"
attribute	Python expression	No	Python script. The value is written to the .v file as the attribute of the port. Example: attribute=">(* AAA, BBB=1 *)" => (* AAA, BBB=1*) input PORT;
port_type	String	No	'data', 'reset' and 'clock' are valid values. The default value is 'data' port_type will be passed to the IPXact component.xml as a lsscip:isClk or lsscip:isRst node in venderExtensions in component/model/ports/port

4. <busInterfaces> node: contains a list of all interface ports of the soft IP (Figure 3.37). The description follows IP-XACT format. Refer to IEEE 1685-2014: IEEE Standard for IP-XACT, Standard Structure for Packaging, Integrating, and Reusing IP within Tool Flows for more details. The busInterface has a list of portMap, which defines logicalPort name and physicalPort name. In <ports> nodes, one port can have optional "bus_interface" attribute, which binds the port with a busInterface. If one port is bound to the busInterface, its name should match physicalPort name of one portMap of the busInterface, so that port and busInterface/portMap is bound together. Whether or not a port can be used is based on user configuration. If the port is used, the corresponding portMap in busInterface is written to the output IP-XACT file. Otherwise, the corresponding portMap in busInterface is not written to the output IP-XACT file.

```

<lscip:busInterfaces>
  <lscip:busInterface>
    <lscip:name>AHBL_S00</lscip:name>
    <lscip:displayName>AHBL_S00</lscip:displayName>
    <lscip:description>AHB-Lite slave
port</lscip:description>
    <lscip:busType library="interface" name="ahblite"
vendor="lattice" version="1.0"/>
    <lscip:abstractionTypes>
      <lscip:abstractionType>
        <lscip:abstractionRef library="interface"
name="ahblite_rtl" vendor="lattice" version="1.0"/>
        <lscip:portMaps>
          <lscip:portMap>
            <lscip:logicalPort>
              <lscip:name>HSEL</lscip:name>
            </lscip:logicalPort>
            <lscip:physicalPort>
<lscip:name>ahbl_s00_hsel_slv_i</lscip:name>
              </lscip:physicalPort>
            </lscip:portMap>
          <lscip:portMap>
            <lscip:logicalPort>
              <lscip:name>HADDR</lscip:name>
            </lscip:logicalPort>
            <lscip:physicalPort>
<lscip:name>ahbl_s00_haddr_slv_i</lscip:name>
              </lscip:physicalPort>
            </lscip:portMap>
          </lscip:portMaps>
        </lscip:abstractionType>
      </lscip:abstractionTypes>
    <lscip:slave>
      <lscip:memoryMapRef memoryMapRef="ahbs_mem_map"/>
    </lscip:slave>
  </lscip:busInterface>
</lscip:busInterfaces>

```

Figure 3.37. Example of busInterface Node

5. <addressSpaces> node: specifies the addressable area seen by bus interfaces of type master (Figure 3.38). The description follows IP-XACT format. Refer to IEEE 1685-2014: IEEE Standard for IP-XACT, Standard Structure for Packaging, Integrating, and Reusing IP within Tool Flows for more details.

```

<lscsip:addressSpaces>
  <lscsip:addressSpace>
    <lscsip:name>ahbm_addr_space</spirit:name>
    <lscsip:range>4k</lscsip:range>
    <lscsip:width>32</lscsip:width>
  </lscsip:addressSpace>
</lscsip:addressSpaces>

```

Figure 3.38. Example of addressSpaces Node

6. <memoryMaps> node: specifies the information about the range of registers, memory, or other address blocks accessible through slave interface (Figure 3.39). The description follows IP-XACT format. Refer to IEEE 1685-2014: IEEE Standard for IP-XACT, Standard Structure for Packaging, Integrating, and Reusing IP within Tool Flows for more details and examples.

To represent dynamic availability of some elements, <register> and <field> node are extended with an optional isPresent element (introduced in IEEE Std 1685-2014), which defines whether the enclosing element is present or not. The value of isPresent element is a Python expression. Parameters defined in <settings> node can be used in the expression.

If a register is used based on user configuration, the register is written to output IP-XACT file. Otherwise, the register is not written to output IP-XACT file.

```

<lscip:memoryMaps>
  <lscip:memoryMap>
    <lscip:name>ahbs_mem_map</lscip:name>
    <lscip:description>AHB-Lite Slave 0 memory
map</lscip:description>
    <lscip:addressBlock>
      <lscip:name>registers</lscip:name>
      <lscip:displayName>registers</lscip:displayName>
      <lscip:description>Register Block</lscip:description>
      <lscip:baseAddress>0</lscip:baseAddress>
      <lscip:range>4096</lscip:range>
      <lscip:width>32</lscip:width>
      <lscip:usage>register</lscip:usage>
      <lscip:access>read-write</lscip:access>
      <lscip:register>
        <lscip:name>Status</lscip:name>
        <lscip:displayName>Status Register</lscip:displayName>
        <lscip:description>Status Register</lscip:description>
        <lscip:addressOffset>0x10</lscip:addressOffset>
        <lscip:size>4</lscip:size>
        <lscip:volatile>true</lscip:volatile>
        <lscip:access>read-only</lscip:access>
        <lscip:field>
          <lscip:name>FIFO_Empty</lscip:name>
          <lscip:displayName>FIFO_Empty</lscip:displayName>
          <lscip:description>Indicates current status of the
interface in the receive direction: 0 - There is data available. 1 - The
FIFO is empty.</lscip:description>
          <lscip:isPresent> 1 != int_setting
</lscip:isPresent>
          <lscip:bitOffset>0</lscip:bitOffset>
          <lscip:bitWidth>1</lscip:bitWidth>
          <lscip:volatile>true</lscip:volatile>
          <lscip:access>read-only</lscip:access>
          <lscip:writeValueConstraint>
            <lscip:minimum>0</lscip:minimum>
            <lscip:maximum>0</lscip:maximum>
          </lscip:writeValueConstraint>
          <lscip:testable
testConstraint="unConstrained">false</lscip:testable>
          </lscip:field>
        </lscip:register>
      </lscip:addressBlock>
    </lscip:memoryMap>
  </lscip:memoryMaps>

```

Figure 3.39. Example of memoryMaps Node

7. <componentGenerators> node: contains a list of componentGenerator elements. Each componentGenerator element defines a generator that is run on generated IP instance package. Each generator is called after other IP instance package files are generated. For example, a component generator can generate memory initialization file for a memory IP (Figure 3.40).

```

<lscsip:componentGenerators>
  <lscsip:componentGenerator>
    <lscsip:name>memGenerator</lscsip:name>
    <lscsip:generatorExe>script/mem_gen.py</lscsip:generatorExe>
  </lscsip:Generator>
</lscsip:Generators>

```

Figure 3.40. Example of componentGenerators Node

8. <estimatedResources> node: contains a list of estimatedResource element. Each estimatedResource element defines the formula to calculate one type of resource used in the IP instance package. Table 3.6 shows the element in < estimatedResource> node.

Table 3.6. Elements in estimatedResources Node

Element	Value	Mandatory	Description
name	String	Yes	Name of the resource.
Number	Python expression	Yes	Python script to calculate the number of the resource.

9. <outFileConfigs> node: specifies all customized output file configuration nodes <fileConfig> for whole customized flow. FileConfig node contains a group of attributes to specify a specific file or directory generation.

A full description of a soft IP might be large. Metadata.xml supports to build a large XML file from small manageable chunks. The approach is implemented by Xinclude (Figure 3.41).

metadata.xml

```
<lscsip:ip version="1.0"
xmlns:lscsip="http://www.latticesemi.com/XMLSchema/Radiant/ip"
xmlns:xi="http://www.w3.org/2001/XInclude">
  <lscsip:general> ... </lscsip:general>
  <xi:include href="setting.xml" parse="xml" />
  <xi:include href="memory_map.xml" parse="xml" />
  <xi:include href="address_space.xml" parse="xml" />
  <xi:include href="bus_interface.xml" parse="xml" />
  <lscsip:ports> ... </lscsip:ports>
</lscsip:ip>
```

setting.xml

```
<lscsip:settings
xmlns:lscsip="http://www.latticesemi.com/XMLSchema/Radiant/ip">
  <lscsip:setting id="int_setting" type="input" value_type="int"
conn_mod="example" default="1" title="Integer Setting" />
  <lscsip:setting id="bool_with_value_mapping" type="param"
value_type="bool" conn_mod="example"
  default="False" bool_value_mapping="('Enabled',
'Disabled')" />
</lscsip:settings>
```

Figure 3.41. Example of Xinclude Usage

You can use [metadata.xsd](#) in [Appendix A](#) to check the metadata file. For those elements borrowed from IPXact, refer to the related xsd files of IPXact.

3.3.2. Implementation RTL Files

You should put all IP implementation RTL files in 'rtl' sub directory of whole IP package. Lattice Builder platform does not support hierarchical rtl directories. All RTL sources can be put in one directory level. Three file suffix names ('.v', '.sv' and '.vhd') are supported for RTL files to represent 'Verilog', 'System Verilog' and 'Vhdl' language types accordingly.

IP Platform always generates a wrapper module by default for the whole IP generation. This wrapper is in Verilog HDL no matter what the language type of the IP implementation RTLs is. Providing a Verilog-HDL top to handle the interface translation among different language types is strongly recommended.

If the IP is implemented in Verilog HDL (including System Verilog) only, all the contents are copied in one .v/.sv RTL file and modules are defined in the wrapper top module. All module names have unified naming rule to avoid name collision such as Top module name, PMI module name, Primitive module name, Blackbox module name.

If some portions of an IP module in the RTL file are encrypted, the corresponding portions generated in Verilog file are also encrypted.

All the RTLs are kept and copied to an IP instance directory, if there is VHDL in IP implementation RTLs. Therefore, the module-naming rule does not need to be unified. You can specify different lib (default is work) for VHDL source that is specified in "wrapper" file generator (Figure 3.42).

```
<lscsip:outFileConfigs>
  <lscsip:fileConfig name="wrapper" lib='test2.vhd=libA;test3.vhd=libB' />
</lscsip:outFileConfigs>
```

Figure 3.42. Example of Specifying Lib for VHDL

3.3.3. Python Script Plugin File

Python expressions can be used in metadata file to implement complex logic. To support complex logic, you can add any python functions in plugin.py file (Figure 3.43) of an IP package, and then call the functions in Python expressions in metadata file.

Each setting item value can be referred to in a Python expression in metadata.xml by its ID as a Python variable. An expression is evaluated by demand. The plugin has its individual namespace and all the setting items values are exported to plugin as a global map variable IP_SETTINGS. You can use IP_SETTINGS [item ID] to refer to an item or set its value in plugin code.

A global variable ‘__PLUGIN_VER’ is defined with value ‘2.0’. You can check this variable if you want to provide a plugin that can work on both current and legacy IP platforms.

```
def cntr_opt():
    #return {"Down" :0,
    #       "Up" :1,
    #       "UpDown":2}
    return [{"Down" : 0},
            {"Up" : 1},
            {"UpDown", 2}]

def cntr_ldir():
    return ((CNTR_DIR == 0) | (CNTR_DIR == 1))

def cntr_wdt():
    if (CNTR_WIDTH < 2):
        return 2
    else:
        return CNTR_WIDTH

def cntr_hval_check():
    if (CNTR_HVALUE <= CNTR_LVALUE):
        ret = 0
        PluginUtil.post_error("Higher count value should be greater than the Lower count value.")
    else:
        ret = 1
    return ret

def get_device_name(value):
    x = runtime_info.device_info.architecture(value)
    return x
```

Figure 3.43. Template of Plugin File

3.3.4. Memory Map CSV File

Propel 2022.1 Builder supports importing memory map from a CSV file to create memory map. You can edit a CSV file. [Figure 3.44](#) shows the CSV file template. Each row to be imported is with one of the keywords among MEMORYMAP, REGISTER, and FIELD. Row with no keyword is ignored, such as the header row (orange squared part in [Figure 3.44](#)). The header row is to help identify the column.

	A	B	C	D	E	F	G	H	I	J
1	0	1	2	3	4	5		7	8	9
2		name	description	baseAddress	range	width				
3	MEMORYMAP	ABC	desc1	0x0		32 64				
4		name	displayName	description	addressOffset	size	volatile	access		
5	REGISTER	QSPI_CTRL	QSPI_CTRL	QSPI Control Register	0x00	32	TRUE	read-write		
6		field	displayName	description	bitOffset	bitWidth	volatile	access	default	testable
7	FIELD	spi_mode	spi_mode	Sets the SPI mode		0 2	TRUE	read-write	DEFAULT_S PI_MODE	TRUE
8	FIELD	sck_div	sck_div	Sets the SPI clock divider		2 3	TRUE	read-write	DEFAULT_S CK_DIV	TRUE
9	FIELD	reserved	reserved	Reserved bits		5 26	TRUE	read-write	0	TRUE
10	FIELD	soft_reset	soft_reset	Resets internal soft logic		31 1	TRUE	read-write	0	TRUE
11		name	displayName	description	addressOffset	size	volatile	access		
12	REGISTER	CMD_DATA	CMD_DATA	Command Data Register	0x04	32	TRUE	read-write		
13		field	displayName	description	bitOffset	bitWidth	volatile	access	default	testable
14	FIELD	cmd_data	cmd_data	Command data to transmit in transaction phase 1 (always big endian)		0 32	TRUE	read-write	0	TRUE
15		name	displayName	description	addressOffset	size	volatile	access		
16	REGISTER	TX_FIFO_DATA	TX_FIFO_DATA	Tx FIFO Data Register	0x08	32	TRUE	write-only		
17		name	displayName	description	bitOffset	bitWidth	volatile	access	default	testable
18	FIELD	tx_fifo_data	tx_fifo_data	Data to transmit in transaction phase 2.		0 32	TRUE	write-only	NA	FALSE

Figure 3.44. Example of Memory Map CSV File

4. TCL Commands

Propel Builder provides TCL commands to execute actions. You can manually enter TCL commands in Tcl Console (Figure 4.1), if you prefer using command lines rather than using the GUI.

```
Tcl Console

% sbp_design close
INFO - Finished: sbp_design close
Finished: "sbp_design close"

% sbp_design open -name hello_v -path {G://Lattice/project/Raptor/tool/hw/hello_v/hello_v/hello_v.sbx}
% sbp_design close
INFO - Finished: sbp_design close
Finished: "sbp_design close"
```

Figure 4.1. Tcl Console

4.1. sbp_design

The sbp_design command is used as one of the high-level management commands such as opening, closing, of the design files created by the Propel Builder.

4.1.1. Open

Opens an existing Propel Builder design for modification.

Usage	sbp_design open -name <design name> -path <design path> [-device <device name>]
Example	sbp_design open -name project1 -path project1.sbx

4.1.2. Close

Closes a Propel Builder design currently opened.

Usage	sbp_design close
--------------	------------------

4.1.3. New

Creates a new Propel Builder design.

Usage	sbp_design new -name <new design name> -path <new design path> -device <device name> -language <language type> -board <board name>
--------------	--

4.1.4. Save

Saves the current Propel Builder design to file on disk or save it as a new file. You can choose to save the design to the project location (Example 1) or to a specific path (Example 2).

Usage	sbp_design save [-path <new design path>]
Example 1	sbp_design save
Example 2	sbp_design save -path new_design.sbx

4.1.5. Drc

Runs the design rule check for the Propel Builder design file.

Usage	<code>sbp_design drc</code>
--------------	-----------------------------

4.1.6. Generate

Generates RTL code to instantiate and connect the IP cores specified in the Propel Builder design file.

Usage	<code>sbp_design generate</code>
--------------	----------------------------------

4.1.7. Auto Assign Addresses

Automatically assigns memory mapped addresses to all the slaves in the system. These addresses should be chosen to avoid slaves with multiple non-contiguous address ranges.

Usage	<code>sbp_design auto_assign_addresses</code>
--------------	---

4.1.8. Verify

Launches the SOC verification engine to verify design.

Usage	<pre>sbp_design verify [-h] [--workfolder <workfolder_path>] [--sbx_file <sbx_file_path>] {sim_gen,pfr_pack,regmap_gen,auto_run}</pre> <p>positional arguments: {sim_gen,pfr_pack,regmap_gen,auto_run} specify the application</p> <pre>sim_gen Simulation Generation Flow pfr_pack PFR Security Engine Packager Flow regmap_gen Memory Map Generation Flow auto_run Automation Flow</pre> <p>optional arguments:</p> <pre>-h, --help show this help message and exit --workfolder WORKFOLDER, -wf WORKFOLDER assign the working folder. Otherwise, the default one (current working folder) will be used --sbx_file SBX_FILE, -sf SBX_FILE specify the sbx file</pre>
Example	<code>sbp_design verify --workfolder ./mem_map --sbx_file D:/XO3D_Initial/XO3D_Initial.sbx regmap_gen</code>

4.1.9. PGE

Runs command with different parameters to call SGE function, DGE function, and Signature inside of PGE (Package Generate Engine).

- Runs command to call SGE to generate files for SDK.

Usage	<pre>sbp_design pge sge -l <input path> [-o <output path>] -i [Required] the top-level SoC project sbx file full path. -o [Optional] output full path, if the parameter is not specified, output path is the same as SoC project path. sge folder is generated at output path, at present sge folder under the SoC project root directory.</pre>
--------------	--

- Runs command to call DGE to generate TCL script that can be used to generate a Diamond or Radiant project.

Usage	<pre>sbp_design pge dge -i <input path> [-o <output path>] [-diamond -radiant]</pre> <p>-i [Required] the top level SoC project sbx file full path. -o [Optional] output full path, if the parameter is not specified, output path is the same as SoC project path. For DGE, tcl script and related files are generated at output path. At present, Diamond or Radiant project share the same workspace with SoC project. -diamond [Optional] flag to execute DGE for diamond project. -radiant [Optional] flag to execute DGE for Radiant project.</p>
--------------	--

- Run command to generate signature.
- PGE gets partial UFM3 contents including version packet(), Sentry PFR configure data (D), and call Flash Address Tool to sign with private key from Factory HSM.

Usage	<pre>sbp_design pge gen_signature -cfile <c binary file> -dfile <d binary file> -output <output binary file></pre>
--------------	--

4.1.10. Undo

Undo operation. Currently, software only supports single undo.

Usage	<pre>sbp_design undo</pre>
--------------	----------------------------

4.1.11. Redo

Redo operation. Currently, software only supports single redo.

Usage	<pre>sbp_design redo</pre>
--------------	----------------------------

4.1.12. Set Device

Modify the device information including device, package, speed, operating condition.

Usage	<pre>sbp_design set_device -device <device name> -speed <speed value> -package <package value> -operating <operating condition></pre>
--------------	---

4.2. Other TCL Commands

The following commands are used for specifying connectivity and IP instantiation to the Propel Builder backend.

4.2.1. sbp_add_component

Instantiates an IP component into the system. Must specify the component VLNV identifier. This corresponds to a component instance in the IP-XACT design. For example, the command below can instantiate an AHB-Lite interconnect component.

Usage	<pre>sbp_add_component -vlv <VLNV> -name <instance_name></pre>
Example	<pre>sbp_add_component -vlv lattice:ip:ahbl_interconnect:1.0 -name ahblite_interconnect</pre>

4.2.2. sbp_add_sbxcomp

Instantiates a hierarchical component from sbx file into the system.

Usage	<code>sbp_add_sbxcomp -name <hname> -path <sbx_file_absolute_path_name></code>
Example	<code>sbp_add_sbxcomp -name sim_comp -path "C:/test/test.sbx"</code>

4.2.3. sbp_add_gluelogic

Instantiates a gluelogic component into the system.

Usage	<code>sbp_add_gluelogic -name <instance_name> -logicinfo <logic json info from sbp_create_glue_logic></code>
Example	<code>sbp_add_gluelogic -name equation_module_inst -logicinfo [sbp_create_glue_logic equation_module {"{"x": "A", "B", "module_a": "equation_module"}]}</code>

Note: This is an internal command. Modify existing usage is not recommended.

4.2.4. sbp_create_glue_logic

Create gluelogic information when adding gluelogic component. rtl_path must be a file path if gluelogic comes from a file. Else be empty.

Usage	<code>sbp_create_glue_logic <type> <module_name> <rtl_path> <json cfg data></code>
Example	<code>sbp_add_gluelogic -name equation_module_inst -logicinfo [sbp_create_glue_logic equation_module {"{"x": "A", "B", "module_a": "equation_module"}]}</code>

Note: This is an internal command. Modify existing usage is not recommended.

4.2.5. sbp_add_port

Creates a top-level I/O port. Must specify the direction.

Usage	<code>sbp_add_port [-from <bit number>] [-to <bit number>] -direction <in/out/inout> <port_name></code>
--------------	---

4.2.6. sbp_modify_port

Modify existing top-level ports to change the width and the direction.

Usage	<code>sbp_modify_port -name <port_name> [-from <bit number>] [-to <bit number>] -direction <dir></code>
--------------	---

4.2.7. sbp_connect_net

Connects all of the specified pins and/or ports to the same net. The arguments can be pins or ports in the system design. Only one of the arguments can be the driver (output pin/port), driving all other input pin/ports. Example below connects the clk port to all components, assuming component pins are all named clk.

Usage	<code>sbp_connect_net [-name <net name>] <pin/port> <pin/port></code>
Example	<code>sbp_connect_net [sbp_get_pins clk] {CLOCK_IN}</code>

4.2.8. sbp_connect_interface_net

Connects a bus interface pin/port to another interface pin/port. This corresponds to the interconnection element in the IP-XACT design.

Usage	<code>sbp_connect_interface_net <pin/port> <pin/port></code>
--------------	--

4.2.9. sbp_connect_constant

Connects a constant integer to a pin/pinbus/port/portbus. To assign to a pin/pinbus, the object must be an input pin/pinbus. To assign to a port/portbus, the object must be an output port/portbus. If the integer requires multiple

bits, not 0 or 1, then the object must be a bus. The tcl command can be used to assign the same constant to multiple pin/pinbus/port/portbus at the same time.

Usage	sbp_connect_constant -constant <integer> <pin/pin bus/ port/portbus> <pin/pin bus/ port/portbus>...
Example	sbp_connect_constant -constant 1 {test/i2c_mst_apb/rst_n_i} {test/riscv/clk_i}

4.2.10. sbp_connect_whitebox

User can do connection cross the hierarchy boundary for verification purpose.

Usage	sbp_connect_whitebox <design_name/vip_inst_name/pin_name> <design_name/uit_inst_name/port_name>
--------------	--

4.2.11. sbp_disconnect_whitebox

Removes the connection cross the hierarchy boundary.

Usage	sbp_disconnect_whitebox <design_name/vip_inst_name/pin_name> <design_name/uit_inst_name/port_name>
--------------	---

4.2.12. sbp_disconnect_interface_net

Disconnects an interface pin/port from the interface nets they attached to. Note that any interface pin or interface port can attach to one interface net at the most.

Usage	sbp_disconnect_interface_net <pin/port> <pin/port>
--------------	--

4.2.13. sbp_disconnect_net

Disconnects all of the specified input pins and/or ports from the nets they attached to. Note that any pin or port can attach to one net at the most. Can also be used to disconnect a constant that is connected to a pin/port with connect_constant.

Usage	sbp_disconnect_net <pin0> <pin1> <port2>
--------------	--

4.2.14. sbp_assign_addr_seg

Assigns a memory map between a pair of master and slave interfaces. Range specifies the range of the segment, for example, 32'h0000400, 32'h0001000. Offset specifies the base offset of the range, for example, 32'h0000400

Usage	sbp_assign_addr_seg -offset <offset> <slave connection name>
Example	sbp_assign_addr_seg -offset 32'h00001000 simple/riscv/AHBL_S00

4.2.15. sbp_unassign_addr_seg

The Tcl command unsets the fixed offset flag for a memory map allowing the auto_assign Tcl command to assign the memory map offset.

Usage	sbp_unassign_addr_seg <slave interface name>
Example	sbp_unassign_addr_seg simple/spi/AHB_S00

4.2.16. sbp_assign_local_memory

Assigns a base address to a local memory map of a master address space.

Usage	sbp_assign_local_memory -offset <offset> <master_addr_space>
Example	sbp_assign_local_memory -offset 'h0050000 Foundation_SoC/riscv/ahbl_m_data_Address_Space

4.2.17. sbp_export_pins

Exports a list of pins or interface pins, or all not-yet-connected pins of the components to the top-level port list in the design. The function detects whether or not the argument is pin(s) or component(s). In the two examples below, Example 1 demonstrates a Tcl command to export the pin `init_done`, while Example 2 demonstrates a Tcl command to export all pins and interfaces of the `ddr3` component.

Usage	<code>sbp_export_pins <pin/component> <pin/component></code>
Example 1	<code>sbp_export_pins {ddr3/init_done}</code>
Example 2	<code>sbp_export_pins {ddr3}</code>

4.2.18. sbp_export_interface

Exports bus interfaces that are passed as arguments to the Tcl command from the component to the top-level component. Example below exports the `AHBL_MASTER` bus interface of the `RISC-V` component to the top-level component.

Usage	<code>sbp_export_interfaces <interface> <interface> <interface></code>
Example	<code>sbp_export_interfaces simple/riscv/AHBL_MASTER</code>

4.2.19. sbp_rename

The `rename` Tcl command renames objects within the design. The new name of the object and the current hierarchical name of the given object are used as the parameter value. The object can be an interface connection, connection, port, interface, or component. The example below demonstrates the changing of the name of a port in milestone project from `CLK` to `CLOCK`.

Usage	<code>sbp_rename -name <new name> <object name></code>
Example	<code>sbp_rename -name CLOCK milestone/CLK</code>

4.2.20. sbp_replace

The `Replace (Re-Config)` Tcl command replaces a component with a new configuration for itself. `VLNV` refers to the newly-generated IP, component name refers to the existing component that is to be replaced, and instance refers to the instance name of the component with new configuration.

Usage	<code>sbp_replace -vlnv <VLNV> -name <instance> -component <component name></code>
Example	<code>sbp_replace -vlnv lattice:ip:ahblite_bus_0:1.1 -name ahbl_bus_0 -component simple/ahblite</code>

4.2.21. sbp_copy

Copies objects, IP instances and nets, from the current or other open sbp designs to the current sbp design. All objects are post-fixed with a postfix string. For example, you can write TCL code below to duplicate the components and connections with new instance names post fixed with `X`, by calling `copy` on all the components, ports and nets. Pins are automatically duplicated while the components are duplicated.

Usage	<code>sbp_copy -postfix <postfixString> objects</code>
Example	<code>sbp_copy -postfix X \$selected_objs</code>

4.2.22. sbp_delete

Deletes objects, IP instances and nets, from the current sbp design. In the examples below, Example 1 demonstrates a Tcl command to delete a port, while Example 2 demonstrates a Tcl command to delete ddr3 component.

Usage	Sbp_delete objects -type <type name>
Example 1	sbp_delete [sbp_get_ports <clock>] -type port
Example 2	sbp_delete {ddr3} -type component

4.2.23. sbp_get_pins

Gets a list of pin names that match a pattern string, and/or the pins that are associated with an object. The object in the [-from <objectName>] option can be a net or a component. The example below gets the clk pin from the interconnect IP.

Usage	sbp_get_pins [-from <object Name>] [pattern]
Example	sbp_get_pins -from ahblite_interconnect clk

4.2.24. sbp_get_interface_pins

Gets a list of interface names that match a pattern string, and/or the interfaces that are associated with an object. The object in the [-from <objectName>] option can be an interface net or a component. The example below can get all AHB-Lite slave interface pins from the interconnect IP.

Usage:	sbp_get_interface_pins [-from <objectName>] [pattern]
Example:	sbp_get_interface_pins -from ahblite_interconnect S*_AHB

4.2.25. sbp_get_ports

Get a list of the names of ports that match a pattern string, and/or the ports that are associated with an object. The object in the [-from <objectName>] option can be a net.

Usage	sbp_get_ports [-from <objectName>] [pattern]
--------------	--

4.2.26. sbp_get_interface_ports

Gets a list of interface names that match a pattern string, and/or the interface ports that are associated with an object. The object in the [-from <objectName>] option can be an interface net.

Usage	sbp_get_interface_ports [-from <objectName>] [pattern]
--------------	--

4.2.27. sbp_get_nets

Gets a list of net names that match a pattern string, and/or the nets that are associated with an object. The object in the [-from <objectName>] option can be a pin or a port.

Usage	sbp_get_nets [-from <objectName>] [pattern]
--------------	---

4.2.28. sbp_get_interface_nets

Gets a list of interface net names that match a pattern string, and/or the interface nets that are associated with an object. The object in the [-from <objectName>] option can be an interface pin or an interface port.

Usage	sbp_get_interface_nets [-from <objectName>] [pattern]
--------------	---

4.2.29. sbp_set_property

Sets the properties of an input object. The first argument is a list of name value pairs. We have a list of parameters because the GUI IP configuration dialog submits changes to many parameters of an IP component at the same time when the dialog is closed. In the examples below, Example 1 changes the data width of the RAM block named “ebr_0”, while Example 2 changes the number of master interfaces to two and number of slave interface to three on AHB-Lite interconnect block named “ahbl_interconnect”.

Usage	sbp_set_property <name0 value0 name1 value1 ...> object
Example 1	sbp_set_property {datawidth 32} {test/ebr_0}
Example 2	sbp_set_property {NUM_MI 2 NUM_SI 3} test/ahbl_interconnect

4.2.30. sbp_get_property

Gets the property of the object. The example below is to get the number of slave interfaces of AHB-Lite interconnect block named “ahbl_interconnect_0”.

Usage	sbp_get_property <parameter name> <object>
Example	sbp_get_property NUM_SI ahbl_interconnect_0

4.2.31. sbp_report_properties

Prints all the properties and values associated to the type of the object.

Usage	sbp_report_properties object
Example	sbp_report_properties ahbl_interconnect
Outputs	Name: ahbl_interconnect NUM_SI: 1 NUM_MI: 2 DATA_WIDTH: 32 ADDRESS_WIDTH: 32

4.2.32. sbp_get_components

Gets a list of component names that match a pattern string, and/or the components that are associated with an object. The default pattern string is a wildcard “*” that matches all components. The pattern string may consist of string segments and wildcards. The example below returns all the component names that contain “interconnect”. The command returns an empty string if no match is found.

Usage	sbp_get_components <component name>
Example	sbp_get_components {*interconnect*}

Appendix A. metadata.xsd

```

<?xml version="1.0" encoding="gb2312"?>
<!-- IP Metadata Schema 0.0.5 -->
<!--
Change Log:
    0.0.0 21-Jul-2016 initial revision.
    0.0.1 22-Jul-2016 1. removed enum_value from <setting> 2. change
value_mapping to scriptType
    0.0.2 29-Jul-2016 1. removed GUI out of metadata scope
    0.0.3 30-Jul-2016 1. add value list support
    0.0.4 07-Jan-2021 1. new features in Radiant 3.0
    0.0.5 06-Apr-2021 1. fully support Verilog macro
-->
<xs:schema xmlns:xs="http://www.w3.org/2001/XMLSchema"
    targetNamespace="http://www.latticesemi.com/XMLSchema/Radiant/ip"
    xmlns:lscip="http://www.latticesemi.com/XMLSchema/Radiant/ip"
    elementFormDefault="qualified"
    attributeFormDefault="unqualified">
    <xs:import schemaLocation="xml.xsd"
namespace="http://www.w3.org/XML/1998/namespace"/>
    <xs:include schemaLocation="busInterface.xsd"/>
    <xs:include schemaLocation="memoryMap.xsd"/>
    <xs:include schemaLocation="file.xsd"/>
    <xs:include schemaLocation="generator.xsd"/>
    <xs:include schemaLocation="design.xsd"/>

    <xs:attributeGroup name="ipany.att">
        <xs:anyAttribute processContents="lax"/>
    </xs:attributeGroup>
    <!-- version string type definition-->
    <xs:simpleType name="threeFigureVersionType">
        <xs:annotation>
            <xs:documentation>
                The syntax for version string.
            </xs:documentation>
        </xs:annotation>
        <xs:restriction base="xs:string">
            <xs:pattern value="[0-9]+\.[0-9]+\.[0-9]+"/>
        </xs:restriction>
    </xs:simpleType>

    <xs:simpleType name="twoFigureVersionType">
        <xs:annotation>
            <xs:documentation>
                The syntax for Radiant version string.
            </xs:documentation>
        </xs:annotation>
        <xs:restriction base="xs:string">
            <xs:pattern value="[0-9]+\.[0-9]+"/>
        </xs:restriction>
    </xs:simpleType>

    <xs:simpleType name="scriptType">

```

```

<xs:annotation>
  <xs:documentation>
    Any python expressions. Could be a simple const variable like
    &quot;l&quot;;,
    or a tuple &quot;(0, 10)&quot;;, or a function call
    &quot;user_func1()&quot;;,
    or a complex expression &quot;a==12&quot;;
  </xs:documentation>
</xs:annotation>
<xs:restriction base="xs:string"/>
</xs:simpleType>

<xs:simpleType name="settingTypeType">
  <xs:annotation>
    <xs:documentation>
      Is this setting variable for parameter of IP core module, verilog macro,
      or just for user input?
      Valid values are &quot;input&quot;;, &quot;verilog_macro&quot;;,
      &quot;param&quot;;, and &quot;command&quot;;.
    </xs:documentation>
  </xs:annotation>
  <xs:restriction base="xs:string">
    <xs:enumeration value="param"/>
    <xs:enumeration value="input"/>
    <xs:enumeration value="verilog_macro"/>
    <xs:enumeration value="command"/>
  </xs:restriction>
</xs:simpleType>
<xs:simpleType name="settingMacroNameType">
  <xs:annotation>
    <xs:documentation>
      Specify what is used to name the Verilog macro, ID or Value?
      Valid values are &quot;id&quot;; and &quot;value&quot;;.
    </xs:documentation>
  </xs:annotation>
  <xs:restriction base="xs:string">
    <xs:enumeration value="id"/>
    <xs:enumeration value="value"/>
  </xs:restriction>
</xs:simpleType>

<xs:simpleType name="settingValueType">
  <xs:annotation>
    <xs:documentation>
      Value type of setting variable. Valid types are &quot;bool&quot;;,
      &quot;string&quot;; and &quot;int&quot;;
    </xs:documentation>
  </xs:annotation>
  <xs:restriction base="xs:string">
    <xs:enumeration value="bool"/>
    <xs:enumeration value="string"/>
    <xs:enumeration value="int"/>
    <xs:enumeration value="float"/>
    <xs:enumeration value="path"/>
  </xs:restriction>
</xs:simpleType>

```

```

        </xs:restriction>
    </xs:simpleType>

    <xs:simpleType name="settingDefaultType">
        <xs:annotation>
            <xs:documentation>
                Default value of setting variable.
            </xs:documentation>
        </xs:annotation>
        <xs:restriction base="xs:string"/>
    </xs:simpleType>

    <xs:simpleType name="settingOutputFormatterType">
        <xs:annotation>
            <xs:documentation>
                Formatter of output.
            </xs:documentation>
        </xs:annotation>
        <xs:restriction base="xs:string">
            <xs:enumeration value="str"/>
            <xs:enumeration value="nostr"/>
        </xs:restriction>
    </xs:simpleType>

    <!-- ip.settings.setting-->
    <xs:complexType name="settingElementType">
        <xs:annotation>
            <xs:documentation>
                Setting variable definition.
            </xs:documentation>
        </xs:annotation>

        <xs:attribute name="id" type="xs:string" use="required" />
        <xs:attribute name="type" type="lscip:settingTypeType"
            use="required" />
        <xs:attribute name="value_type" type="lscip:settingValueType"
            use="required" />
        <xs:attribute name="conn_mod" type="xs:string" use="required" />
        <xs:attribute name="domain" type="xs:string" use="optional" />
        <xs:attribute name="default" type="lscip:settingDefaultType"
            use="optional" />
        <xs:attribute name="value_expr" type="lscip:scriptType"
            use="optional" />
        <xs:attribute name="drc" type="lscip:scriptType" use="optional" />
        <xs:attribute name="editable" type="lscip:scriptType"
            use="optional" />
        <xs:attribute name="description" type="xs:string" use="optional" />
        <xs:attribute name="title" type="xs:string" use="optional" />
        <xs:attribute name="hidden" type="xs:string" use="optional" />
        <xs:attribute name="regex" type="xs:string" use="optional" />
        <xs:attribute name="options" type="lscip:scriptType"
            use="optional" />
        <xs:attribute name="value_range" type="lscip:scriptType"
            use="optional" />
    </xs:complexType>

```

```

<xs:attribute name="group1" type="xs:string" use="optional" />
<xs:attribute name="group2" type="xs:string" use="optional" />
<xs:attribute name="bool_value_mapping" type="lscsip:scriptType"
  use="optional" />
<xs:attribute name="output_formatter"
  type="lscsip:settingOutputFormatterType" use="optional" />
<xs:attribute name="config_groups" type="lscsip:scriptType"
  use="optional" />
<xs:attribute name="process_path" type="xs:boolean" use="optional"
  default="true">
</xs:attribute>
<xs:attribute name="macro_name" type="lscsip:settingMacroNameType"
use="optional"
  default="id">
</xs:attribute>
<xs:attribute ref="xml:base" use="optional"/>
<xs:attribute name="no_dependency" type="xs:string" use="optional" />
</xs:complexType>

<!-- ip.settings -->
<xs:complexType name="settingsType">
  <xs:sequence>
    <xs:element minOccurs="0" maxOccurs="unbounded" name="setting"
type="lscsip:settingElementType" />
  </xs:sequence>
  <xs:attribute ref="xml:base" use="optional"/>
</xs:complexType>

<!-- ip.ports.port-->
<xs:complexType name="portElementType">
  <xs:annotation>
    <xs:documentation>IP port definition.</xs:documentation>
  </xs:annotation>
  <xs:attribute name="name" type="xs:string" use="required" />
  <xs:attribute name="dir" type="xs:string" use="required" />
  <xs:attribute name="conn_mod" type="xs:string" use="required" />
  <xs:attribute name="conn_port" type="xs:string" use="optional" />
  <xs:attribute name="conn_range" type="xs:string" use="optional" />
  <xs:attribute name="range" type="lscsip:scriptType"
    use="optional" />
  <xs:attribute name="stick_high" type="lscsip:scriptType"
    use="optional" />
  <xs:attribute name="stick_low" type="lscsip:scriptType"
    use="optional" />
  <xs:attribute name="stick_value" type="lscsip:scriptType"
    use="optional" />
  <xs:attribute name="dangling" type="lscsip:scriptType"
    use="optional" />
  <xs:attribute name="bus_interface" type="xs:string"
    use="optional" />
  <xs:attribute name="attribute" type="lscsip:scriptType"
    use="optional" />
  <xs:attribute name="port_type" use="optional" default="data">
    <xs:simpleType>

```

```

        <xs:restriction base="xs:string">
            <xs:enumeration value="data"></xs:enumeration>
            <xs:enumeration value="reset"></xs:enumeration>
            <xs:enumeration value="clock"></xs:enumeration>
        </xs:restriction>
    </xs:simpleType>
</xs:attribute>
<xs:attribute ref="xml:base" use="optional"/>
</xs:complexType>
<!-- ip.outFileConfigs -->
<xs:complexType name="outFileConfigsType">
    <xs:sequence>
        <xs:element maxOccurs="unbounded" name="fileConfig"
type="lscip:fileConfigType" />
    </xs:sequence>
</xs:complexType>
<!-- ip.outFileConfigs.fileConfig -->
<xs:complexType name="fileConfigType">
    <xs:annotation>
        <xs:documentation>Configure output file</xs:documentation>
    </xs:annotation>
    <xs:attribute name="name" type="xs:string" use="required" />
    <xs:attribute name="use" use="optional" default="merge">
        <xs:annotation>
            <xs:documentation>
                Merge the new attributes to existing configuration or
                replace all
            </xs:documentation>
        </xs:annotation>
    </xs:annotation>
    <xs:simpleType>
        <xs:restriction base="xs:string">
            <xs:enumeration value="merge"></xs:enumeration>
            <xs:enumeration value="replace"></xs:enumeration>
        </xs:restriction>
    </xs:simpleType>
</xs:attribute>
<xs:attribute name="type" use="optional" default="file">
    <xs:annotation>
        <xs:documentation>
            Indicate the item is generate a file or directory
        </xs:documentation>
    </xs:annotation>
    <xs:simpleType>
        <xs:restriction base="xs:string">
            <xs:enumeration value="file"></xs:enumeration>
            <xs:enumeration value="directory"></xs:enumeration>
        </xs:restriction>
    </xs:simpleType>
</xs:attribute>
<xs:attribute name="description" type="xs:string"
    use="optional">
</xs:attribute>
<xs:attribute name="enable_output" type="xs:string" use="optional"
    default="True">

```

```

        <xs:annotation>
            <xs:documentation>
                Python expression represent a boolean value to
                indicate the output is enabled or disabled
            </xs:documentation>
        </xs:annotation>
    </xs:attribute>
    <xs:attribute name="phase" type="xs:int" use="optional"
        default="0">
    </xs:attribute>
    <xs:attribute name="file_base_name" type="xs:string"
        use="optional">
    </xs:attribute>
    <xs:attribute name="file_suffix" type="xs:string"
        use="optional">
    </xs:attribute>
    <xs:attribute name="sub_dir" type="xs:string"
use="optional"></xs:attribute>
    <xs:attribute name="file_generator" type="xs:string"
        use="optional">
    </xs:attribute>
    <xs:attribute name="src_dir" type="xs:string"
        use="optional">
    </xs:attribute>
    <xs:attribute name="dest_dir" type="xs:string"
        use="optional">
    </xs:attribute>
    <xs:attribute name="src_file" type="xs:string"
        use="optional">
    </xs:attribute>
    <xs:attribute name="export" use="optional" default="input_only">
        <xs:annotation>
            <xs:documentation>
                Indicate export all setting items or input only
            </xs:documentation>
        </xs:annotation>
        <xs:simpleType>
            <xs:restriction base="xs:string">
                <xs:enumeration value="all"></xs:enumeration>
                <xs:enumeration value="input_only"></xs:enumeration>
            </xs:restriction>
        </xs:simpleType>
    </xs:attribute>
    <xs:attributeGroup ref="lscsip:ipany.att"/>
</xs:complexType>
<!-- ip.interface-->
<xs:complexType name="portsType">
    <xs:sequence>
        <xs:element maxOccurs="unbounded" minOccurs="1" name="port"
type="lscsip:portElementType" />
    </xs:sequence>
    <xs:attribute ref="xml:base" use="optional"/>
</xs:complexType>

```

```

<!-- ip.interface-->
<xs:complexType name="generalType">
  <xs:sequence>
    <xs:element maxOccurs="1" minOccurs="0" name="vendor"
      type="xs:string" />
    <xs:element maxOccurs="1" minOccurs="0" name="library"
      type="xs:Name" />
    <xs:element maxOccurs="1" minOccurs="1" name="name"
      type="xs:string" />
    <xs:element maxOccurs="1" minOccurs="0" name="display_name"
      type="xs:string" />
    <xs:element maxOccurs="1" minOccurs="1" name="version"
      type="xs:string" />
    <xs:element maxOccurs="1" minOccurs="1" name="category"
      type="xs:string" />
    <xs:element maxOccurs="1" minOccurs="0" name="keywords"
      type="xs:string" />
    <xs:element maxOccurs="1" minOccurs="0" name="type"
      type="xs:string" />
    <xs:element maxOccurs="1" minOccurs="0" name="instantiatedOnce"
      type="xs:boolean" />
    <xs:element maxOccurs="1" minOccurs="1"
      name="min_radiant_version" type="lscsip:twoFigureVersionType" />
    <xs:element maxOccurs="1" minOccurs="0"
      name="max_radiant_version" type="lscsip:twoFigureVersionType" />
    <xs:element maxOccurs="1" minOccurs="0" name="min_esi_version"
      type="lscsip:twoFigureVersionType" />
    <xs:element maxOccurs="1" minOccurs="0" name="max_esi_version"
      type="lscsip:twoFigureVersionType" />
    <xs:element maxOccurs="1" minOccurs="1"
      name="supported_products" type="lscsip:supportedProductsType" />
    <xs:element maxOccurs="1" minOccurs="0"
      name="supported_platforms" type="lscsip:supportedPlatformsType" />
  </xs:sequence>
</xs:complexType>

<xs:complexType name="supportedPlatformsType">
  <xs:sequence>
    <xs:element maxOccurs="unbounded" minOccurs="1" name="supported_platform"
      type="lscsip:supportedPlatformType" />
  </xs:sequence>
</xs:complexType>

<xs:complexType name="supportedPlatformType">
  <xs:sequence>
    <xs:element maxOccurs="unbounded" minOccurs="0" name="supported_templates"
      type="lscsip:supportedTemplatesType" />
  </xs:sequence>
  <xs:attribute name="name" type="xs:string"/>
</xs:complexType>

<xs:complexType name="supportedTemplatesType">
  <xs:sequence>

```

```

    <xs:element maxOccurs="unbounded" minOccurs="0" name="supported_template"
type="lscsip:supportedTemplateType" />
  </xs:sequence>
</xs:complexType>

<xs:complexType name="supportedTemplateType">
  <xs:attribute name="processor" type="xs:string"/>
  <xs:attribute name="family" type="xs:string"/>
  <xs:attribute name="name" type="xs:string"/>
  <xs:attribute name="version" type="xs:string" use="optional"/>
</xs:complexType>

<xs:complexType name="supportedProductsType">
  <xs:sequence>
    <xs:element maxOccurs="unbounded" minOccurs="1" name="supported_family"
type="lscsip:supportedFamilyType" />
  </xs:sequence>
</xs:complexType>

<xs:complexType name="supportedFamilyType">
  <xs:sequence>
    <xs:element maxOccurs="unbounded" minOccurs="0" name="supported_device"
type="lscsip:supportedDeviceType" />
  </xs:sequence>
  <xs:attribute name="name" type="xs:string"/>
</xs:complexType>

<xs:complexType name="supportedDeviceType">
  <xs:sequence>
    <xs:element maxOccurs="unbounded" minOccurs="0"
name="supported_speed_grade" type="lscsip:supportedSpeedType" />
  </xs:sequence>
  <xs:attribute name="name" type="xs:string"/>
</xs:complexType>

<xs:complexType name="supportedSpeedType">
  <xs:sequence>
    <xs:element maxOccurs="unbounded" minOccurs="0" name="supported_package"
type="lscsip:supportedPackageType" />
  </xs:sequence>
  <xs:attribute name="name" type="xs:string"/>
</xs:complexType>

<xs:complexType name="supportedPackageType">
  <xs:attribute name="name" type="xs:string"/>
</xs:complexType>

<!-- ip.estimatedResources -->
<xs:complexType name="estimatedResourcesType">
  <xs:annotation>
    <xs:documentation>
      IP estimated resources definition.
    </xs:documentation>
  </xs:annotation>

```

```

        <xs:sequence>
            <xs:element name="estimatedResource" type="lscchip:estimatedResourceType"
minOccurs="1" maxOccurs="unbounded"/>
        </xs:sequence>
    </xs:complexType>

    <xs:complexType name="estimatedResourceType">
        <xs:sequence>
            <xs:element name="name" type="xs:string"/>
            <xs:element name="number" type="xs:string"/>
        </xs:sequence>
    </xs:complexType>

    <!-- ip -->
    <xs:element name="ip">
        <xs:complexType>
            <xs:sequence>
                <xs:element name="general" type="lscchip:generalType" />
                <xs:element name="settings" type="lscchip:settingsType" />
                <xs:element name="ports" type="lscchip:portsType" />
                <xs:element name="outFileConfigs" type="lscchip:outFileConfigsType"
maxOccurs="1" minOccurs="0">
                    <xs:unique name="fileCfgKey">
                        <xs:selector xpath="lscchip:fileConfig"/>
                        <xs:field xpath="@name"/>
                    </xs:unique>
                </xs:element>
                <xs:element ref="lscchip:busInterfaces" minOccurs="0" />
                <xs:element ref="lscchip:addressSpaces" minOccurs="0" />
                <xs:element ref="lscchip:memoryMaps" minOccurs="0" />
                <xs:element ref="lscchip:componentGenerators" minOccurs="0" />
                <xs:element ref="lscchip:choices" minOccurs="0" />
                <xs:element ref="lscchip:fileSets" minOccurs="0" />
                <xs:element ref="lscchip:design" minOccurs="0"
maxOccurs="unbounded"/>
                <xs:element name="estimatedResources"
                    type="lscchip:estimatedResourcesType" minOccurs="0" />
                <xs:element ref="lscchip:parameters" minOccurs="0" />
            </xs:sequence>
            <xs:attribute name="version" type="lscchip:twoFigureVersionType"/>
            <xs:attribute name="platform" type="xs:string" use="optional"/>
            <xs:attribute name="platform_version" type="lscchip:twoFigureVersionType"
use="optional"/>
        </xs:complexType>
    </xs:element>

</xs:schema>

```

References

- [Lattice Propel 2022.1 SDK User Guide \(FPGA-UG-02176\)](#)
- [Lattice Propel 2022.1 Installation for Windows Usage Guide \(FPGA-AN-02056\)](#)
- [Lattice Propel 2022.1 Installation for Linux User Guide \(FPGA-AN-02057\)](#)
- [Lattice Diamond Online Help](#)
- [Lattice Radiant Online Help](#)

Technical Support Assistance

Submit a technical support case through www.latticesemi.com/techsupport.

Revision History

Revision 1.0, November 2022

Section	Change Summary
All	Production release.



www.latticesemi.com