



GPIO IP

IP Version: v1.8.1

Release Notes

FPGA-RN-02026-1.2

June 2026

Disclaimers

Lattice makes no warranty, representation, or guarantee regarding the accuracy of information contained in this document or the suitability of its products for any particular purpose. All information herein is provided AS IS, with all faults, and all associated risk is the responsibility entirely of the Buyer. The information provided herein is for informational purposes only and may contain technical inaccuracies or omissions, and may be otherwise rendered inaccurate for many reasons, and Lattice assumes no obligation to update or otherwise correct or revise this information. Products sold by Lattice have been subject to limited testing and it is the Buyer's responsibility to independently determine the suitability of any products and to test and verify the same. LATTICE PRODUCTS AND SERVICES ARE NOT DESIGNED, MANUFACTURED, OR TESTED FOR USE IN LIFE OR SAFETY CRITICAL SYSTEMS, HAZARDOUS ENVIRONMENTS, OR ANY OTHER ENVIRONMENTS REQUIRING FAIL-SAFE PERFORMANCE, INCLUDING ANY APPLICATION IN WHICH THE FAILURE OF THE PRODUCT OR SERVICE COULD LEAD TO DEATH, PERSONAL INJURY, SEVERE PROPERTY DAMAGE OR ENVIRONMENTAL HARM (COLLECTIVELY, "HIGH-RISK USES"). FURTHER, BUYER MUST TAKE PRUDENT STEPS TO PROTECT AGAINST PRODUCT AND SERVICE FAILURES, INCLUDING PROVIDING APPROPRIATE REDUNDANCIES, FAIL-SAFE FEATURES, AND/OR SHUT-DOWN MECHANISMS. LATTICE EXPRESSLY DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY OF FITNESS OF THE PRODUCTS OR SERVICES FOR HIGH-RISK USES. The information provided in this document is proprietary to Lattice Semiconductor, and Lattice reserves the right to make any changes to the information in this document or to any products at any time without notice.

Inclusive Language

This document was created consistent with Lattice Semiconductor's inclusive language policy. In some cases, the language in underlying tools and other items may not yet have been updated. Please refer to Lattice's inclusive language [FAQ 6878](#) for a cross reference of terms. Note in some cases such as register names and state names it has been necessary to continue to utilize older terminology for compatibility.

Contents

Contents	3
1. Introduction	4
GPIO IP v1.8.1	4
Corrections to Previous Release Notes	4
GPIO IP v1.8.0	4
GPIO IP v1.7.0	4
GPIO IP Earlier Versions	4
References	5
Technical Support Assistance	6

1. Introduction

This document contains the Release Notes for the GPIO IP. For specific details about the IP, refer to the following:

- [GPIO IP User Guide \(FPGA-IPUG-02076\)](#)

GPIO IP v1.8.1

Software	Software Version	Summary of Changes
Lattice Radiant™ Lattice Propel™	2026.1	Fixed an issue that caused a “License checkout failed” error. This IP is distributed without a license. Note: There are no updates to the IP user guide for this release. Refer to the GPIO IP User Guide (FPGA-IPUG-02076, v2.4) for the applicable documentation.

Corrections to Previous Release Notes

- The Lattice Propel software supports all IP versions listed below.

GPIO IP v1.8.0

Software	Software Version	Summary of Changes
Lattice Radiant	2025.1	Updated the Customer Testbench GSR.

GPIO IP v1.7.0

Software	Software Version	Summary of Changes
Lattice Radiant	2024.2	Added the APB interface support for the iCE40 UltraPlus devices.

GPIO IP Earlier Versions

IP Version	Summary of Changes
1.6.2	Updated the driver to add version information and remove warnings.
1.6.1	Updated the APB to the LMMI bridge.
1.6.0	Added support for all devices.
1.5.0	• Added support for CertusPro-NX devices. • Updated the GSR instance in the testbench.
1.4.1	Fixed the combinational loop.
1.4.0	Added support for MachXO2, MachXO3L, and MachXO3LF devices.
1.3.0	• Added an option to remove tri-state buffer. • Added support for Mach-NX devices.
1.2.0	Added support for MachXO3D and Certus-NX devices.
1.1.0	Added support for CrossLink-NX devices.
1.0.0	Initial release.

References

- [GPIO IP User Guide \(FPGA-IPUG-02076\)](#)
- [Certus-N2](#) web page
- [Certus-NX](#) web page
- [CertusPro-NX](#) web page
- [CrossLink-NX](#) web page
- [iCE40 UltraPlus](#) web page
- [GPIO IP Core](#) web page
- [Lattice Propel Design Environment](#) web page
- [Lattice Radiant Software](#) web page
- [Lattice Insights](#) web page for Lattice Semiconductor training courses and learning plans

Technical Support Assistance

Submit a technical support case through www.latticesemi.com/techsupport.

For frequently asked questions, please refer to the Lattice Answer Database at www.latticesemi.com/Support/AnswerDatabase.



www.latticesemi.com