



Release Notes for Lattice Diamond 3.6

Welcome to Lattice Diamond[®], the complete design environment for Lattice Semiconductor FPGAs. Lattice Diamond design software offers leading-edge design and implementation tools optimized for cost-sensitive, low-power Lattice FPGA architectures.

Diamond is available for both the Windows and Linux operating systems. For details, see “System Requirements” on page 8.

This version of Diamond adds a variety of enhancements to make designing for Lattice Semiconductor programmable devices easier than ever. The design tools also include support for the latest Lattice Semiconductor devices. See “What’s New” on page 2.

Lattice Semiconductor offers a rich variety of information sources, including the Help system, PDF manuals, tutorials, and online discussions. The easiest way to reach them all is through the online Help. The first topic in the [Help](#) provides links to all the other sources of information.

You can also find extensive information about Diamond and its capabilities, tools, and workflow on the Lattice Semiconductor website under:

www.latticesemi.com/latticediamond

What's New

This release of Diamond provides a variety of new features in the following areas. See the online Help for details.

Clarity Designer A new option, Single Module Generation, is available when working with Clarity Designer. This option simplifies the generation process when working with only one module. For more information, open the online Help and go to **User Guides > Entering the Design > Creating Clarity Designer Modules > Basic Tasks > Running Clarity Designer**.

Lattice Synthesis Engine Lattice Synthesis Engine (LSE) has updated optimization settings.

- ▶ If set to **Area**, LSE will choose smaller design forms over faster whenever possible.
- ▶ If set to **Timing**, LSE will choose faster design forms over smaller whenever possible. If a create_clock constraint is available in an .ldc file, LSE ignores the Target Frequency setting and uses the value from the create_clock constraint instead.
- ▶ If you are having trouble meeting one requirement (area or speed) while optimizing for the other, try setting this option to **Balanced**.

For more information, open the online Help and go to **Implementing the Design > Synthesizing the Design > Optimizing LSE for Area and Speed**.

LatticeMico System Support for cable server has been added.

MachXO3LF MachXO3LF now supports the following:

- ▶ Mixed voltage in I/O bank (like MachXO2)
- ▶ 900 MBPS MIPI

MachXO3LF to MachXO3L Low-cost Migration MachXO3LF designs that do not use User Flash Memory (UFM) can be migrated to lower-cost MachXO3L devices and a valid bitstream can be generated. For more information, open the online Help and go to **Implementing the Design > Bit Generation > Generating Bitstream Files**.

Netlist Analyzer Netlist Analyzer has the following new features:

- ▶ List Clock Tree
- ▶ Group scalar ports into port buses by pattern for Lattice primitives
- ▶ Sort nets by fan-out number in find dialog
- ▶ Schematic bookmark capability

For more information, open the online Help and go to **Managing Projects > Analyzing a Design > About Netlist Analyzer** and **Managing Projects > Analyzing a Design > About Netlist Analyzer > Setting Netlist Analyzer Options**.

Preferences MULTICYCLE preference has been enhanced to handle more cases to relax clock domains created from clock enable.

Programmer Soft Error Injection (SEI) support has been added, as a “beta release,” for MachXO2 and MachXO3LF/LF devices. For more information, open the online Help and go to **Programming the FPGA > Programmer Options > Device Properties Dialog Box - Device, Access Mode, and Operation Options**.

For ECP5, MachXO2 and MachXO3LF devices, a JTAG “XSRAM SEI Fast Program” operation has been added. For more information, open the online Help and go to **Programming the FPGA > Programmer Options > Device Properties Dialog Box - Device, Access Mode, and Operation Options**.

Programming File Utility I2C Slave Address can now be changed in the Feature Row Editor of Programming File Utility. If the “I2C Persistent Disable” bit is 1, the feature row I2C Slave Address bits will be enabled for editing. If the “I2C Persistent Disable” bit is 0, the feature row I2C Slave Address bits will be disabled for editing. For more information, open the online Help and go to **Programming the FPGA > Using Programming File Utility > Editing Feature Row Values**.

Reveal Support for cable server has been added.

Spreadsheet View For MachXO3L/LF devices, a new DUALBOOTGOLDEN preference has been added. MachXO3L/LF devices can optionally boot from two patterns, a primary bitstream and a golden bitstream. If the primary bitstream is found to be corrupt while being downloaded into the SRAM, the device shall then automatically re-boot from the golden bitstream. The DUALBOOTGOLDEN preference defines if the Golden file is Internal (on-chip Flash/NVCM) or External (SPI Flash).

For MachXO2 and MachXO3L/LF devices, a new BACKGROUND_RECONFIG preference has been added to enable or disable the background re-configuration capability.

Refer to **Applying Design Constraints > Using Preferences > Global Preferences**, and **Constraints Reference Guide > Preferences > SYSCONFIG**.

Supported Devices

Lattice Diamond can be used with either a free license or a subscription license. The two licenses provide access to different device families.

Device Family	Free License	Subscription License
ASC	◀	◀
ECP5U	◀	◀
ECP5UM		◀

Device Family	Free License	Subscription License
LatticeEC™	◀	◀
LatticeECP™	◀	◀
LatticeECP2™	◀	◀
LatticeECP2M™		◀
LatticeECP2S		◀
LatticeECP2MS		◀
LatticeECP3™		◀
LatticeSC™		◀
LatticeSCM™		◀
LatticeXP™	◀	◀
LatticeXP2™	◀	◀
MachXO™	◀	◀
MachXO2™	◀	◀
MachXO3L	◀	◀
Platform Manager™	◀	◀
Platform Manager 2	◀	◀

Updating Projects from an Earlier Version

If you want to work on a design project created with an earlier version of Diamond, start with the following procedures. These procedures adapt the project for the changes in Diamond.

Find out which version of Diamond your project was created with. Then work through the changes for that and every later version, starting with the earliest and going to the most recent. For example, if your project was created with Diamond 1.1, you would start with the changes for 1.1. After completing those changes, you would work on the changes for 1.2, then 1.4, and so on.

When you open a project from Diamond 1.2 or earlier, Diamond opens a dialog box warning that Diamond will automatically move all SDC files to the Synthesis Constraint Files folder in File List view and remove the “Input SDC Constraint File” options from the strategies. If the project is using LSE, the file names will be changed to use an .lsc extension.

Once saved, the project will not be compatible with earlier Diamond versions.

2.2 Projects

ECP5 does not use the CIN port of the CCU2C Carry Chain primitive. This port should not be connected to anything. If the port is connected, the Design Map stage will fail with an error message. If you see such a failure, correct the design in one of the following ways:

- ▶ Rerun synthesis. This should correct the problem if the CCU2C primitive is part of an IPexpress module.
- ▶ If the CCU2C primitive was added to your HDL manually, edit the code to remove the connection. See the following examples:

In Verilog:

```
CCU2C addsub_0 (.A0(scuba_vlo), .A1(DataA[0]),
               .B0(scuba_vlo), .B1(DataB[0]), .C0(scuba_vhi),
               .C1(scuba_vhi), .D0(scuba_vhi), .D1(scuba_vhi),
               .CIN()), .S0(), .S1(Result[0]), .COUT(co0));
```

In VHDL:

```
signal tmp: std_logic := 'X';
cnt_cia: CCU2C
  generic map (INJECT1_1=> "NO", INJECT1_0=> "NO",
              INIT1=> X"0000", INIT0=> X"0000")
  port map (A0=>scuba_vhi, A1=>scuba_vhi, B0=>scuba_vhi,
           B1=>scuba_vhi, C0=>scuba_vhi, C1=>scuba_vhi,
           D0=>scuba_vhi, D1=>scuba_vhi,
           CIN=>tmp, S0=>open, S1=>open, COUT=>cnt_ci);
```

2.0.1 Projects

Several strategy options have new default values. If you are using Synplify Pro in integrated mode (running synthesis automatically in Diamond), check that the following settings are still as you want them. Also, check the setting of the Auto Hold-Time Correction option under Place & Route Design. Its default changed to On for all devices.

Table 1: New Default Values for Synplify Pro for Lattice

Option	Before	Now
Fanout Limit is now Fanout Guide	100	1000
Export Diamond Settings to Synplify Pro GUI (new in 2.2)	Not available	No
Fix Gated Clocks and Fix Generated Clocks combined into new Clock Conversion	3 (converts and reports all sequential elements)	True (converts with no report)
Frequency	200	auto (blank means "auto")
Number of Critical Paths	3	blank (unspecified)
Number of Start/End Points	0	blank (unspecified)

Table 1: New Default Values for Synplify Pro for Lattice (Continued)

Option	Before	Now
Output Preference File	False	True
Pipelining and Retiming	False	Pipelining Only
Resolved Mixed Drivers	True	False
Use Clock Period for Unconstrained I/O	True	False

1.4 Projects

For Diamond 1.4 and earlier, there might be some constraints that are not honored because of the Synplify Pro cross-probing feature. This EDIF renaming is usually related to bus names.

If such a problem occurs, you can turn off the renaming feature by placing the following line in the “Command line Options” text box of the Synplify Pro section of the active strategy:

```
set_option -syn_edif_array_rename 0
```

1.2 Projects

There were several enhancements for IP and MachXO2.

IP Incompatibilities

SPI4.2 2.7 is not compatible with Diamond 1.3 or later. If you are using this IP, check the Lattice Semiconductor Web site for a more recent version.

MachXO2 Changes

See if your design involves any of the following features:

- ▶ For EFB modules with user flash memory (UFM), regenerate the module.
- ▶ For IO_TYPE=PCI33 on a MachXO2-1200 or larger device, check if the CLAMP is using the default setting. With Diamond 1.3 the CLAMP default changes from ON to PCI and the I/O will be placed in bank 2. If you were using the default and still want the setting to be ON, you need to set it explicitly.
- ▶ For PCI33 MT 6.5 and PCI33 T 6.4 IP, either set the CLAMP to ON explicitly or choose a bigger package (256 or more).

1.1 or 1.0 Projects

There were several enhancements for IP and MachXO2.

IP Incompatibilities

The following IP versions are not compatible with Diamond 1.2 or later. If you are using any of these IP, check the Lattice Semiconductor Web site for a more recent version.

- ▶ Convolution Block Encoder 3.6
- ▶ Interleaver Deinterleaver 3.5
- ▶ DDR1 6.9
- ▶ PCI_MT_33 6.4
- ▶ DDR2 7.1
- ▶ PCIe RC Lite 1.2
- ▶ DDR3 1.2.1
- ▶ Tri-Speed MAC 3.4
- ▶ DDR1_CP 1.1 with MachXO2
- ▶ Viterbi Block Decoder 4.6
- ▶ DDR2_CP 1.1 with MachXO2

MachXO2 Support

Some aspects of the software support for MachXO2 designs have been improved. See if your design involves any of the following features:

- ▶ The 4K/7K design with PLL has a CIB-to-PLL jump change. If you are using this design, recompile it.
- ▶ The EFB simulation model has changed. If you are using the EFB module, rerun your simulation tests to see more accurate results.
- ▶ In the DDR_GENERIC module of IPexpress, the GDDR1_RX.Aligned with PLL interface is no longer supported. If you are using such a module, use IPexpress to regenerate it without the PLL option.

Also, MachXO2 has IP evaluation capability and TransFR mode for all I/Os.

Migrating ispLEVER Projects

Diamond uses a different project structure than ispLEVER and cannot directly open an ispLEVER project. However, design projects created in ispLEVER can easily be imported into Diamond. The process is automatic except for the ispLEVER process properties, which are similar to the Diamond strategy settings, and some modules and IPs. All of your ispLEVER project source will be automatically handled.

Projects created using ispLEVER can be imported into Lattice Diamond through two different paths:

- ▶ On the Start Page, click **Import ispLEVER Project** (in the upper-left corner).
- ▶ From the File menu, choose **Open > Import ispLEVER Project**.

Follow the directions in the dialog box that opens to convert your ispLEVER project into a Lattice Diamond project.

Limitations to the import/conversion process include:

- ▶ NGO files in ispLEVER projects need to be manually copied into the Lattice Diamond project if the NGO files were originally copied into the ispLEVER project. For example, NGO files that were copied from Lattice IP generation.
- ▶ The .lpc files are replaced with .ipx files in Lattice Diamond. You need to regenerate your IP by double-clicking on the .lpc file. The resultant wizard will help you generate the new .ipx file, replacing the old .lpc file.

More information on importing ispLEVER projects can be found in the *Lattice Diamond User Guide*, online Help (see **Managing Projects > Importing ispLEVER Projects**), and training videos on the Lattice Web site.

Other Information Resources

Other available information resources for the Diamond software include the following.

- ▶ **General Information:** General information on Lattice Diamond can be found on the Lattice Web site at:
www.latticesemi.com/latticediamond
- ▶ **Online Help:** Start Lattice Diamond and choose **Help > Lattice Diamond Help**.
- ▶ *Lattice Diamond User Guide:* This document can be found from a link on the Start Page view.
- ▶ **Training Videos:** Several short videos are available on different aspects of the Lattice Diamond software. These can be viewed online at:
www.latticesemi.com/latticediamond
Click the **Videos** tab.

System Requirements

The basic system requirements for Lattice Diamond are:

- ▶ Intel Pentium or Pentium-compatible PC, or AMD Opteron system support (Linux only)
- ▶ CPU with the SSE3 instruction set to run the Aldec Active-HDL Lattice Edition simulator
- ▶ One of the following operating systems:
 - ▶ Windows Vista (32-bit), Windows 7 (32-bit or 64-bit), or Windows 8 (32-bit or 64-bit), including Windows 8.1.

- ▶ Red Hat Enterprise Linux 4.X, 5.3, or 6. The host operating system can be either 32-bit or 64-bit.
Version 5.3 of Red Hat Enterprise Linux has some extra installation requirements. See “Configuring Red Hat 5.3” on page 10.
- ▶ Novell SUSE Linux Enterprise 10 SP1 or 11 operating system. Novell SUSE Linux supports 32-bit only.
- ▶ Approximately 5.75 GB free disk space
- ▶ RAM adequate for your FPGA design. For guidelines see “Memory Requirements” on page 9.
- ▶ Network adapter and, for a floating license, network connectivity
A node-locked license is based on the physical (hard-coded) address provided by the network adapter. Network connectivity is not required for a node-locked license. In the absence of a network connection, you can install the NWLink IPX/SPX protocol to force recognition of your NIC card ID (see the Installation Notice).
A floating license requires access to the license server, so both a network adapter and connectivity are required.
- ▶ JavaScript-capable Web browser
- ▶ Microsoft Internet Explorer 8 or higher if using the included Aldec Active-HDL Lattice Edition simulator
- ▶ Acrobat Reader 5.0 or later

Memory Requirements

Table 2 lists the minimum memory requirements and the recommended memory for the Lattice Semiconductor devices supported by Diamond.

On Windows, designing for the largest FPGAs may require more than the usual 2 GB of memory found in 32-bit computers. For help in extending your memory to 3 GB, see “Extending Memory on Windows” on page 10. Designing for LatticeECP3 with more than 95K LUT on a Windows system requires a 64-bit operating system.

Table 2: Recommended Memory

Device	Size	32-Bit Operating Systems		64-Bit Operating Systems	
		Minimum	Recommended	Minimum	Recommended
ECP5	All	2 GB	3 GB	4 GB	6 GB
LatticeEC, LatticeECP	Up to 20K LUT	512 MB	768 MB	1 GB	1.5 GB
	Up to 50K LUT	768 MB	1 GB	1.5 GB	2 GB
LatticeECP2/M	Up to 20K LUT	768 MB	1 GB	1.5 GB	2 GB
	Up to 50K LUT	1 GB	1.5 GB	2 GB	3 GB
	Up to 100K LUT	1 GB	2 GB	2 GB	4 GB

Table 2: Recommended Memory (Continued)

Device	Size	32-Bit Operating Systems		64-Bit Operating Systems	
		Minimum	Recommended	Minimum	Recommended
LatticeECP3	Up to 95K LUT	2 GB	3 GB	4 GB	6 GB
	Up to 150K LUT	3 GB	4 GB	6 GB	8 GB
LatticeSC/M	Up to 40K LUT	768 MB	1 GB	1.5 GB	2 GB
	Up to 115K LUT	1 GB	2.5 GB	2 GB	5 GB
LatticeXP, LatticeXP2	Up to 20K LUT	512 MB	768 MB	1 GB	1.5 GB
	Up to 50K LUT	768 MB	1 GB	1.5 GB	2 GB
MachXO, MachXO2, MachXO3L	All	256 MB	512 MB	512 MB	1 GB
Platform Manager, Platform Manager 2	All	256 MB	512 MB	512 MB	1 GB

Extending Memory on Windows

Designing for LatticeECP3 or ECP5 may require more than the 2 GB normally available with 32-bit Windows systems. But you can configure Windows to use up to 3 GB of memory.

Note that increasing the amount of memory available to applications decreases the amount available for the file cache, paged pool, and nonpaged pool, which can affect applications with heavy networking or I/O.

Use the `BCDEdit /set increaseuserva 3072` command to set the boot entry option to 3 GB. For details, see Microsoft article "BCDEdit /set": msdn.microsoft.com/en-us/library/ff542202.aspx

Configuring Red Hat 5.3

Red Hat Enterprise Linux 5.3 has some extra requirements for Diamond:

- ▶ In addition to the basic installation of Red Hat 5.3, under Development/Legacy Software Development, select:

```
1:gtk+-1.2.10-56.el5.i386 - GIMP Toolkit (GTK+) sb:(9 of 9)
```

Under Base System/Legacy Software Support, add the following to the default items:

```
Openmotif22-2.2.3-18.i386 - Open Motif runtime
```

Proper Diamond operation depends upon these libraries being installed.

- ▶ When installing the Red Hat Enterprise Linux version, be sure to install the PERL modules XML::Parser, XML::DOM, and XML::RegExp. These PERL modules are available at www.cpan.org.

Known Issues

Following are known issues with this release and workarounds for them. For the complete list, see:

www.latticesemi.com/view_document?document_id=50676

Netlist Analyzer

Netlist Analyzer Will Not Display HDL Source Files When a Reveal Module is Inserted in the Design

If you are running the design with Reveal flow enabled, the following Netlist Analyzer operations will not work:

- ▶ Netlist Analyzer will not display the corresponding RTL source when you double-click on an object.
- ▶ Netlist Analyzer will not display the corresponding RTL source when you right-click an object and chose **Jump to > Jump to HDL**.

Devices affected: All
CR125194

Programmer

“Slave SPI SEI Fast Program” programming operation fails

The “Slave SPI SEI Fast Program” programming operation fails.

Devices affected: ECP5U/UM
CR125240

Contacting Technical Support

FAQs The first place to look. The [Answer Database](#) on the Lattice Semiconductor Web site provides solutions to questions that many of our customers have already asked. Lattice Applications Engineers are continuously adding to the Database.

Technical Support Assistance Submit a technical support case via www.latticesemi.com/techsupport.

For Local Support Contact your nearest [Lattice Sales Office](#).

Trademarks

All Lattice trademarks are as listed at www.latticesemi.com/legal. Synopsys and Synplify Pro are trademarks of Synopsys, Inc. Aldec and Active-HDL are trademarks of Aldec, Inc. All other trademarks are the property of their respective owners.