QSPI Flash Controller IP

IP Version: v1.5.0

Release Notes

Disclaimers

Lattice makes no warranty, representation, or guarantee regarding the accuracy of information contained in this document or the suitability of its products for any particular purpose. All information herein is provided AS IS, with all faults, and all associated risk is the responsibility entirely of the Buyer. The information provided herein is for informational purposes only and may contain technical inaccuracies or omissions, and may be otherwise rendered inaccurate for many reasons, and Lattice assumes no obligation to update or otherwise correct or revise this information. Products sold by Lattice have been subject to limited testing and it is the Buyer's responsibility to independently determine the suitability of any products and to test and verify the same. LATTICE PRODUCTS AND SERVICES ARE NOT DESIGNED, MANUFACTURED, OR TESTED FOR USE IN LIFE OR SAFETY CRITICAL SYSTEMS, HAZARDOUS ENVIRONMENTS, OR ANY OTHER ENVIRONMENTS REQUIRING FAIL-SAFE PERFORMANCE, INCLUDING ANY APPLICATION IN WHICH THE FAILURE OF THE PRODUCT OR SERVICE COULD LEAD TO DEATH, PERSONAL INJURY, SEVERE PROPERTY DAMAGE OR ENVIRONMENTAL HARM (COLLECTIVELY, "HIGH-RISK USES"). FURTHER, BUYER MUST TAKE PRUDENT STEPS TO PROTECT AGAINST PRODUCT AND SERVICE FAILURES, INCLUDING PROVIDING APPROPRIATE REDUNDANCIES, FAIL-SAFE FEATURES, AND/OR SHUT-DOWN MECHANISMS. LATTICE EXPRESSLY DISCLAIMS ANY EXPRESS OR IMPLIED WARRANTY OF FITNESS OF THE PRODUCTS OR SERVICES FOR HIGH-RISK USES. The information provided in this document is proprietary to Lattice Semiconductor, and Lattice reserves the right to make any changes to the information in this document or to any products at any time without notice.

Inclusive Language

This document was created consistent with Lattice Semiconductor's inclusive language policy. In some cases, the language in underlying tools and other items may not yet have been updated. Please refer to Lattice's inclusive language FAQ 6878 for a cross reference of terms. Note in some cases such as register names and state names it has been necessary to continue to utilize older terminology for compatibility.

Contents

1. Introduction

This document contains the Release Notes for the QSPI Flash Controller IP and QSPI Driver. For specific details about the IP and driver, refer to the following:

- QSPI Flash Controller IP User Guide (FPGA-IPUG-02248)
- QSPI Driver API Reference (FPGA-TN-02339)

QSPI Flash Controller IP v1.5.0

Software	Software Version	Summary of Changes
Lattice Radiant™	2025.1	Driver release v25.01.00. • Fixed bug for transaction status checking in write and read function.

QSPI Flash Controller IP v1.4.0

Software	Software Version	Summary of Changes
Lattice Radiant	2024.2	• Updated SPI clock mode options to 0 and 3. • Updated Transmit FIFO address depth options. • Added support for AXI4 multiple bursts for direct write access. • Added burst transfer for enabled flash address mapping and FIFOs are enabled for register-based access configurations. • Updated IP driver.

QSPI Flash Controller IP Earlier Versions

IP Version	Summary of Changes
1.3.0	• Added LIFCL, LFMXO5, and LN2-CT device support. • Added XiP pattern IP GUI attribute. • Transmit and receive FIFO features are already supported. • Added generic command feature support to enable XiP of other flash devices. • Supported AXI4 multiple bursts for direct read access.
1.2.0	• Added AXI4 direct access and XiP for Macronix™ features support. • Updated interrupt signal. • Updated IP driver.
1.1.5	Updated AHB-L direct access feature implementation.
1.1.4	• Added LFD2NX device support. • Added AHB-L direct access feature support.
1.1.3	• Added LAV-AT device support. • Added multiple SPI target feature support. • Updated IP GUI and registers. • Updated implementation of supported commands with varying command, address and data IO lanes on SPI interface. • Updated customer testbench.
1.1.2	• Fixed SPI clock and data alignment. • Updated supported commands feature implementation.
1.1.1	Updated IP driver.
1.1.0	Added LFCPNX device support.
1.0.0	Initial release.

References

- QSPI Flash Controller IP User Guide (FPGA-IPUG-02248)
- QSPI Driver API Reference (FPGA-TN-02339)
- Avant-E web page
- Avant-G web page
- Avant-X web page
- Certus-N2 web page
- Certus-NX web page
- CertusPro-NX web page
- CrossLink-NX web page
- MachXO5-NX web page
- QSPI Flash Controller IP Core web page
- Lattice Radiant Software web page
- Lattice Propel Design Environment web page
- Lattice Solutions IP Cores web page
- Lattice Solutions Reference Designs web page
- Lattice Insights for Lattice Semiconductor training courses and learning plans

Technical Support Assistance

Submit a technical support case through www.latticesemi.com/techsupport.

For frequently asked questions, please refer to the Lattice Answer Database at www.latticesemi.com/Support/AnswerDatabase